



Technical support: +49 (0)7223 / 9493-0



9<sup>th</sup> edition 10/2000

#### **Copyright**

All rights reserved. This manual is intended for the manager and its personnel. No part of this publication may be reproduced or transmitted by any means. Offences can have penal consequences.

#### Guarantee and responsibility

Basically are effective our "general terms of delivery and payment". The manager receives them at the latest with the invoice. Claims for guarantee and responsibility in case of injuries and material damages are excluded, if they are due to one or some of the following causes:

- if the board has not been used for the intended purpose
- improper installation, operation and maintenance of the board
- if the board has been operated with defective safety devices or with not appropriate or non-functioning safety equipment
- nonobservance of the instructions concerning: transport, storage, inserting the board, use, limit values, maintenance, device drivers
- altering the board at the user's own initiative
- altering the source files at the user's own initiative
- not checking properly the parts which are subject to wear
- disasters caused by the intrusion of foreign bodies and by influence beyond the user's control.

#### Licence for ADDI-DATA software products

Read carefully this licence before using the software. The right for using this software is given to the customer, if he/she agrees to the conditions of this licence.

- this software can only be used for configuring ADDI-DATA boards.
- copying the software is forbidden (except for archiving/ saving data and for replacing defective data media).
- deassembling, decoding and reverse engineering of the software are forbidden.
- this licence and the software can be transferred to a third party, so far as

this party has purchased a board, declares to agree to all the clauses of this licence contract and the preceding owner has not kept copies of the software.

#### **Trademarks**

Borland C and Turbo Pascal are registered trademarks of Borland International, INC. Burr-Brown is a registered trademark of Burr-Brown Corporation

Intel is a registered trademark of Intel Corporation

AT, IBM, ISA and XT are registered trademarks of International Business Machines Corporation

Microsoft, MS-DOS, Visual Basic and Windows are registered trademarks of Microsoft Corporation

#### The original version of this manual is in German. You can obtain it on request.



## $\star\star\star$ Protect yourself, other people and the environment $\star\star\star$

• Read the yellow safety leaflet carefully !

If this leaflet is not with the documentation, please contact us.

## • Do observe the instructions in the manual !

Make sure that you have not skipped any step. We are not liable for damage resulting from the improper use of the board.

• Symbols used



WARNING!

designates a possibly dangerous situation. If the instructions are ignored **the board**, **PC and/or peripheral devices may be damaged**.



**IMPORTANT!** designates hints and other useful information.

## • Do you have any questions?

Our technical support is always glad to help you.

# **CE** Declaration of Conformity

This declaration is valid for the following product:

#### ADDICOM PA 732 Asynchronous Communication Adapter with Full Galvanic Isolation

It is made by

ADDI-DATA GmbH Meß- und Steuerungstechnik Dieselstraße 3 D-77833 Ottersweier

in sole responsibility and is valid on the understanding that the product is competently installed, used and maintained, according to the respective security regulations as well as to the manufacturer's instructions regarding its intended use.

This declaration states that the product complies with following EC Directives:

- EWGRL 336/89 of 3.05.1989
- EWGRL 31/92 of 28.04.1992
- EWGRL 68/93 of 22.07.1993

This declaration is valid for all units manufactured according to the manufacturing references listed in the form TD7500.020. Following norms have been applied to test the product regarding electromagnetic compatibility:

- EN55011/03.91
- EN55022/08.94
- EN50082-2/03.95

We point out that

- the conformity and herewith the permission of use expire if the user alters the product without consulting with the manufacturer.
- non-skilled users are to have the operational area of the product and the requirements resulting from it checked prior to putting into operation.
- by using this product in appliances coming under the EC EMC Directive, the user is to make sure they are conform to its regulations prior to putting into operation.
- by using this product in machines / installations coming under the EU Machine Directive, the user is to make sure they are conform to its regulations prior to putting into operation.

A copy of the EMC tests is at your disposal on request.

H. Hue H-

15 October 1995

Legally valid signature of the manufacturer

1	INTENDED PURPOSE OF THE BOARD	.1
2	USER	.2
2.1	Qualification	.2
2.2	Personal protection	.2
3	HANDLING THE BOARD	.3
4		.4
4.1	Electromagnetic compatibility (EMC)	.4
4.2	Physical set-up of the board	.4
4.3	Options	.5
4.4	Limit values	.5
5	SETTINGS	.6
5.1	Component scheme	.6
<b>5.2</b> 5.2.1 5.2.2	Jumper settings Location of the jumpers on the board and settings at delivery Jumper settings Base address Interrupt lines Mode selection Terminal resistors Controlling the transmitter Controlling the transmitter Selection of the reference potential Selection of the reference potential Selection of the current source for Current Loop Control of the modem control signals Selection of the DMA channel	.7 .7 .8 .9 .9 10 11 11 11
5.3	Setting the base address	12
6	INSERTING THE BOARD	4
6.1	Opening the PC	14
6.2	Selecting a free slot	14
6.3	Plugging the board into the slot	15
6.4	Closing the PC	15

7	SOFTWARE		
7.1	Delivered Software	.16	
7.2	Software installation	.16	
<b>7.3</b> 7.3.1 7.3.2 7.3.3 7.3.4 7.3.5	Board configuration with ADDIREG. Installing ADDIREG Program description Registering a new board Changing the registration of a board. Removing the ADDIREG program.	17 18 21 22 23	
<b>7.4</b> 7.4.1 7.4.2	Installing the drivers Installation under DOS and Windows 3.11 Installation under Windows NT/95/98	<b>24</b> 24 24	
7.5	Questions and software downloads	.25	
8		26	
9	FUNCTIONS OF THE BOARD	27	
9.1	Block diagram	.27	
9.2	I/O mapping	.28	
<b>9.3</b> 9.3.1 9.3.2	<b>R\$232.</b> Jumper settings Wiring principle for R\$232 mode	<b>28</b> 28 29	
<b>9.4</b> 9.4.1 9.4.2 9.4.3	<b>RS422</b> . Jumper settings Release of the RS422 sender. Wiring principle for RS422 mode. Terminal resistors for RS422	<b>29</b> 30 31 32	
<b>9.5</b> 9.5.1 9.5.2 9.5.3	<b>R\$485.</b> Jumper settings Sender release Control of the receiver. Terminal resistors in R\$485 mode.	<b>33</b> 33 33 34 35	
<b>9.6</b> 9.6.1 9.6.2 9.6.3	20mA current loop (TTY) Jumper settings Configuration of the current source Wiring for 20mA current loop (TTY) Active transmission/active reception Active transmission/passive reception Passive transmission/active reception Passive transmission/passive reception	.37 37 38 38 38 38 39 39	
9.7	Reference potential for the damping diodes	.41	
9.8	DMA mode	43	

10	TROUBLE SHOOTING	44
10.1	No communication	44
10.2	Reception of wrong data	44
10.3	Transmission possible, but no reception	44
11	STANDARD SOFTWARE	45
INDE	X	A

## **Figures**

Fig. 3-1: Wrong handling	3
Fig. 3-2: Correct handling	3
Fig. 5-1: Component scheme	6
Fig. 5-2: Location of the jumpers on the board and settings at delivery	7
Fig. 5-3: DIP switches	13
Fig. 6-1: Types of slots	14
Fig. 6-2: Opening the blister pack	14
Fig. 6-3: Inserting the board	15
Fig. 6-4: Fastening the board at the back cover	15
Fig. 7-1: Installation of the ADDIREG program	17
Fig. 7-2: ADDIREG registration program	18
Fig. 7-3: Configuring a new board	20
Fig. 7-4: The ADDI_UNINSTALL program	23
Fig. 7-5: Installation of the examples under Windows NT/95/98	24
Fig. 8-1: 25-pin SUD-D male connector	26
Fig. 9-1: Block diagram of the PA 732	27
Fig. 9-2: Wiring for RS232 mode	29
Fig. 9-3: RS422 sender release	30
Fig. 9-4: RS422 wiring without modem control	31
Fig. 9-5: RS422 wiring with modern control (Option RC)	31
Fig. 9-6: Terminal resistor	32
Fig. 9-7: Insertion of a terminal resistor in the CTS reception lines (Option RC)	33
Fig. 9-8: Setting of the sender release with the control signals DTR, RTS or DATA D	IR
via jumper J6	34
Fig. 9-9: Adjustment of the receiver release via J23	35
Fig. 9-10: Terminal resistor	
Fig. 9-11: Wiring for R\$485	
Fig. 9-12: Active transmission/active reception	
Fig. 9-13: Active transmission/passive reception	
Fig. 9-14: Passive transmission/active reception	
Fig. 9-15: Passive transmission/passive reception	
Fig. 9-16: Connection to a Siemens S5	40
Fig. 9-17: Selection of the reference potential for the damping diodes	42

## Tables

Table 5-1: Setting the base address	8
Table 5-2: Selection of the interrupt lines	8
Table 5-3: Mode selection	9
Table 5-4: Terminal resistors	9
Table 5-5: Transmitter control	10
Table 5-6: Receiver control with J23	10
Table 5-7: Selection of the reference potential with J9	11
Table 5-8: Selection of the current source with J16 and J17	11
Table 5-9: Control of the modem control signals	11
Table 5-10: Selection of the DMA channel	12
Table 5-11: Decoding the base address (0390H)	13
Table 8-1: Pin assignment	
Table 9-1: I/O mapping of the PA 732	

## 1 INTENDED PURPOSE OF THE BOARD

The **PA 732** board is an interface between an industrial process and a personal computer (PC). It is to be used in a free PC ISA slot. The PC is to comply with the EU directive 89/336/EEC and the specifications for EMC protection.

Products complying with these specifications bear the  $\mathbf{CE}$  mark.

Serial data is exchanged with external communication devices through the 25-pin SUB-D connector of the **PA 732** board in the chosen transmission mode (RS232, RS422, RS485 or 20 mA current loop).

The connection with the external cables is to comply with the specifications:

- metallized plastic hoods
- shielded cable
- cable shield folded back and firmly screwed to the connector housing.

The use of the board in a PC could change the PC features regarding to noise emission and immunity. Increased noise emission or decreased noise immunity could result in the system not being conform anymore. Check the PC's and cable's shielding capacity prior to putting the device into operation.

The use of the board according to its intended purpose includes observing all advises given in this manual and the safety leaflet. Uses beyond these specifications are not allowed.

The manufacturer is not liable for any damages which would result from the non-observance of this clause.

## **CAUTION!**

The board is intended to work in one operating mode only. Please read chapter 9 "Functions of the board".

## 2 USER

## 2.1 Qualification

Only persons trained in electronics are entitled to perform the following works:

- installation,
- use,
- maintenance.

## 2.2 Personal protection

Consider the country-specific regulations about

- the prevention of accidents
- electrical and mechanical installations
- radio interference suppression.

## 3 HANDLING THE BOARD

## Fig. 3-1: Wrong handling



Fig. 3-2: Correct handling



## 4 TECHNICAL DATA

## 4.1 Electromagnetic compatibility (EMC)

The board has been subjected to EMC tests in an accredited laboratory in accordance with the norms EN50082-2, EN55011, EN55022. The board complies as follows with the limit values set by the norm EN50082-2:

	<u>True value</u>	<u>Set value</u>
ESD	4 kV	4 kV
Fields	10 V/m	10 V/m
Burst	4 kV	2 kV
Conducted radio interferences	10 V	10 V



### WARNING!

The EMC tests have been carried out in a specific appliance configuration. We guarantee these limit values **only** in this configuration<sup>1</sup>).

#### Consider the following aspects:

- your test program must be able to detect operation errors.
- your system must be set up so that you can find out what caused errors.

## 4.2 Physical set-up of the board

The board is assembled on a 4-layer printed circuit card.



<sup>1)</sup> We transmit our appliance configuration on request.

**Option U:** 

4.4

	<b>Option S:</b> Addressing through DIP switches			
	<b>Option RC:</b> Modem control signals CTS, RTS as RS422 signals			
Lim	nit values			
	Operating ten Storage tempe Relative humi	nperature: erature: idity:	0 to 60°C -25 to 70°C 30% to 95% non condensing	
	Minimum PC - operating sy	C requirements: stem:	MS DOS 3.3, Windows 3.1, Windows NT/95/98	
	Data transfer RS232: RS422/485: 20mA current	r rate:	max. 19.2kBaud max. 56kBaud max. 19.2kBaud	
	20mA current Current cons	t loop: sumption:	≤ 400Ω +5V / 100mA typ. +12V / 80mA typ.	
	Overvoltage RS232: RS422/RS485	protection:	Breakdown voltage = $\pm 25V$ VCL <sup>1</sup> = $\pm 38V$ ; by Ipp <sup>2</sup> = 40A in 8-20 µs test Ppp <sup>3</sup> : SURGE = 300W/1ms Breakdown voltage = $\pm 6.5V$	
			VCL = $\pm 11.3$ V; by Ipp = 35,4A in 1 ms test Ppp = 400W/1ms	
	All channels a 20mA current	are protected against short-circuits by P t loop:	TC resistors. Breakdown voltage: $\pm 26V$ VCL = $\pm 41,5V$ ; by Ipp = 9,6A in 1 ms test Ppp = $400W/1ms$	
	Isolation volt	tage:	1000 VAC	

UART with 16-byte FIFO buffers

5

<sup>&</sup>lt;sup>1</sup> VCL = Clamping Voltage

 $<sup>^{2}</sup>$  Ipp = Surge non repetitive reverse current.

 $<sup>3 \</sup>text{ Ppp} = \text{Peak Pulse Power}$ 

## 5 SETTINGS

## 5.1 Component scheme

### Fig. 5-1: Component scheme



## 5.2 Jumper settings

## 5.2.1 Location of the jumpers on the board and settings at delivery





## 5.2.2 Jumper settings



### WARNING!

**Do not operate** the board simultaneously in several modes. Otherwise you may destroy the board, PC and/or the peripheral.

Make sure to set only the jumpers required for the respective functions.

#### **Base address**

You can also set the base address through DIP switches (Option S). See Chapter 5.3: Base address.

Description	Address	Jumper	settings	Settings at delivery
COM1	3F8H	J] 00	J2 • •	-
COM2	2F8H	J] 00	J2 • •	~
COM3	3E8H	J] 00	J2 • •	-
COM4	2E8H	J] 00	J2 • •	-

Table 5-1: Setting the base address

### Interrupt lines

Table 5-2	: Selection	of the	interrupt	lines
-----------	-------------	--------	-----------	-------

Base address	Corresponding interrupt line	Jumper	Settings at delivery
COM1	IRQ4	J4-2 + J22	-
COM2	IRQ3	J4-1 + J22	~
COM3	IRQ10	J4-4 + J22	-
	IRQ11	J4-5 + J22	-
COM4	IRQ5	J4-3 + J22	-
	IRQ15	J4-6 + J22	-
	no IRQ	J4 and J22 are not set	

#### Mode selection

The board cannot simultaneously operate in several modes. **J9 is always set.** 

Jumper	Settings	Function	Settings at delivery
J14	set	RS232	>
J15	set	RS422, RS485	-
J13	K <b>J13</b> 0 0 0 L	Source of the CTS signal: CTS in RS232 mode	~
	K <b>J13</b> 0 0 0 L	Source of the CTS signal: CTS in RS422 mode (Option RC)	-
J20	set	<b>Current Loop</b>	
J7	J7 0 E 0 F	<b>Current loop - Transmitter</b> Current flows in rest state	✓
	J7 0 E F	Current does not flow in rest state	-
J8	<b>ј8</b> ооо	<b>Current loop - Receiver</b> Current flows in rest state	-
	J8 0 G 0 H	Current does not flow in rest state	-

#### Table 5-3: Mode selection

#### **Terminal resistors**

Jumper	Settings	Function	Settings at delivery
J5	J5 0 A 0 B	RS422, RS485 = $100 \Omega$ terminal resistor	~
	J5 0 A 0 B	RS422, RS485 = $120 \Omega$ terminal resistor	-
J10	set	<b>Option RC:</b> terminal resistor for the CTS signal, when board operated in RS422	-

#### Controlling the transmitter

Settings	Function	Settings at delivery			
C O O O D <b>J6</b> O E	RS485: Control occurs over the DTR signal	-			
C O O O D <b>J6</b> O E	RS485: Control occurs over the DATA-DIR signal	~			
COOD J6 OE	RS485: Control occurs over the RTS signal	-			
J18 0 M 0 N	RS422: sender permanently released.	~			
J18 0 M 0 N	RS422: The release of the sender is programmed via the <b>DTR</b> bit	-			

#### Table 5-5: Transmitter control

# Important!To switch to RS422 the jumper J6 is not to be set.

## Controlling the receiver

#### Table 5-6: Receiver control with J23

Settings	Function	Settings at delivery			
<b>J23</b> POOO	J23 POOO   Alternate control (without echo)				
<b>J23</b> POOOO	Control through the RD-EN bit (with echo)	~			



## **IMPORTANT!**

To switch to RS422, J23 is to be set in position P.

### Selection of the reference potential

Settings	Function	Settings at delivery
J J9	Derivation of the interference voltage via secondary ground DC/DC converter	~
J9 0 0 0	Derivation of the interference voltage via pin 1 of the 25-pin SUB-D connector	-

#### Table 5-7: Selection of the reference potential with J9

#### Selection of the current source for Current Loop

Table 5-8: Selection of	the current source	with J16 and J17
-------------------------	--------------------	------------------

Settings	Function	Settings at delivery
<b>J16</b> 0000 4 3 2 1	Sender current source: active transmission (the board provides constant current)	-
<b>J16</b> 0000 4321	Sender current source: passive transmission (the peripheral provides constant current)	~
<b>J17</b> 0000 4 3 2 1	<b>Receiver current source:</b> active reception (the board provides constant current)	-
<b>J17</b> 0 0 0 0 4 3 2 1	Receiver current source: passive reception (the peripheral provides constant current)	~

#### Control of the modem control signals

Table 5-	9: Control	of the	modem	control	signals
----------	------------	--------	-------	---------	---------

Settings	Function	Settings at delivery
○ ○ J21	The modem control signals are controlled via the 25-pin SUB-D male connector	-
○ ○ J21	The modem control signals are internally wired (DTR $\rightarrow$ DCD, DSR RTS $\rightarrow$ CTS)	~

#### Selection of the DMA channel

In DMA mode, J12 is always to be set.

#### Table 5-10: Selection of the DMA channel

Settings	Function	Settings at delivery
DMA0 O DMA0 O DMA1 O O DMA1 O O DMA3 O DMA3 O J11 J3	-	~
DMA0 O DMA0 O DMA1 O O DMA1 O O DMA3 DMA3 J J11 J3	<b>Example:</b> The DMA channel 1 is selected	-

## 5.3 Setting the base address



#### WARNING!

If the base address set is wrong, the board and/or the PC may be destroyed.

## Before installing the board

Check, that

- the base address is free

- the address range required by the board is not already used by the PC or by boards already installed in the PC.

#### Possible settings of the base address (see also "Jumper settings")

You can find out which serial and parallel ports are already used by your PC.

#### • Load the DEBUG program

Are recognised:

COM1, COM2, LPT1, LPT2 for DOS 3.3 and COM1-COM4, LPT1-LPT2 for >DOS 4.0

Enter	On the screen	Meaning
	C:>	
debug <return></return>	-	
d40:0 <return></return>	F8 03 F8 02 00 00 00 00 -78 03	'address 03F8 = COM1 ´address 02F8 = COM2 ´address 0378 = LPT1
q <return></return>		

COM1 = 03F8, COM2 = 02F8, LPT1=0378 are used in this example by the PC. You can set the base address of the serial ports through the block of DIP switches (Option S). In this case the jumpers J1 and J2 are to be open.

#### Address ranges

• Make sure that the address ranges of the serial ports do not overlap.

#### Decoding of the base addresses

The address decoding requires 8 bytes in the I/O address space. (0 to 3FF Hex).

#### Table 5-11: Decoding the base address (0390H)

	MSE	3														LSB
Decoded address bus	A15	A14	A13	A12	A11	A10	A9	A8	A7	A6	A5	A4	A3	A2	A1	A0
Required Base address Hex	0			3			9			0						
Required Base address binary	0	0	0	0	0	0	1	1	1	0	0	1	0	0	0	0
DIP switsches Logic "0"= ON Logic "1" = OFF	*	*	*	*	*	s1 ON	s2 OFF	s3 OFF	s4 OFF	s5 ON	s6 ON	s7 OFF	s8 ON	X	X	Х

X: Decoded address range of the board

\* : Permanently decoded at logic "0"

#### Fig. 5-3: DIP switches

#### **IMPORTANT!**

You will find the switch **s1 on the left** of the DIP switches!

ON								
	s1	s2	s3	s4	s5	s6	s7	s8
OFF								

If you want to set the board PA 732 with DIP switches to COM1-COM4, the switches S1 to S8 are to be set to OFF.

1

## 6 INSERTING THE BOARD

### **IMPORTANT!**

Do observe the *safety instructions*.

## 6.1 Opening the PC

- Switch off your PC and all the units connected to the PC.
- Pull the PC mains plug from the socket.
- Open your PC as described in the manual of the PC manufacturer.

## 6.2 Selecting a free slot

Two types of ISA slots are available: XT and AT.

Fig. 6-1: Types of slots

AT = XT =	<u> </u>	+~	$\sim$

If necessary, the board can also be used in EISA slots.

See in the PC manual which types of slots are free.

**Remove the back cover of the selected slot** according to the instructions of the PC manufacturer. Keep the back cover. You will need it if you remove the board.

Discharge yourself from electrostatic charges.

Take the board out of its protective blister pack.





## 6.3 Plugging the board into the slot

- Discharge yourself from electrostatic charges.
- Insert the board vertically into the chosen slot.

Fig. 6-3: Inserting the board



• Fasten the board to the rear of the PC housing with the screw which was fixed on the back cover.



#### Fig. 6-4: Fastening the board at the back cover

• Tighten all the loosed screws.

## 6.4 Closing the PC

• Close your PC as described in the manual of the PC manufacturer.

## 7 SOFTWARE

## 7.1 Delivered Software

The board is supplied with a CD-ROM.

The CD contains ADDIREG for Windows NT 4.0 and Windows 95/98, You can also download the ADDIREG program from Internet.

### • IMPORTANT! Do install the A

**Do install the ADDIREG program first**, before you install and start any other applications.

The CD-ROM contains also software examples for the ADDI-DATA communication boards:

- 16-bit for MS-DOS and Windows 3.11
- 32-bit for Windows NT/95/98.

## 7.2 Software installation

- **Install and configure** the boards one after the other. You will thus avoid configuration errors.
- 1. Switch off the PC
- 2. Install the first board
- 3. Start the PC
- 4. Install ADDIREG (once is enough)
- 5. Configure the board
- 6. Install the driver and the software examples
- 7. Switch off the PC
- 8. Install the **second** board
- 9. Start the PC
- 10. Configure the second board
- 11. Install the driver and the software examples

### • IMPORTANT! To install the la

**To install the latest version of ADDIREG**, first deinstall the former version through the ADDI\_UNINSTALL program. (See paragraph 7.3.5).

## 7.3.1 Installing ADDIREG

- Change to the CD drive.

#### - 🗆 × 🔯 Explorer - Disk1 Datei Bearbeiten Ansicht Extras ? 🗈 街 📶 🛦 🖻 🛍 🗠 🗙 🖆 🖦 📰 🏢 🔄 Disk1 • Alle Ordner Inhalt von 'Disk1' 🖻 🦲 Cdrom \* Name Größe Тур . 🕀 🧰 ADDIMON 32-Bi 🛋 \_inst32i.ex\_ 313 KB EX\_-Datei 🗄 🚞 ADDIMON 32-Bi 🗂 \_isdel.exe 8 KB Anwendung 🗄 💼 Addireg 🔄 \_setup.1 765 KB 1-Datei — 🔄 Disk1 🔊 \_setup.dll 6 KB Programmbibli... 🗄 🧰 Disk2 🔊 \_setup.lib 218 KB LIB-Datei 🗄 📄 Disk3 🔊 Disk1.id 1 KB ID-Datei 🗄 🚞 Disk4 Setup.exe 44 KB Anwendung 🕀 🧰 ADDIUNINSTAL 🐻 Setup.ini 1 KB Konfiguration... 🗄 💼 Apci035 为 Setup.ins Einstellungen ... 66 KB 🗄 🧰 Apci1016 🔊 Setupliss 1 KB ISS-Datei 🗄 🚞 Apci1500 PKG.Distai <u>Satun nka</u> 1 K R Þ 43,8 KB 1 Objekt(e) markiert

#### Fig. 7-1: Installation of the ADDIREG program

- Start the Set-up file.
- Select one of the 3 parameters
  - 1- typical
  - 2- compact
  - 3- custom

Proceed as indicated on the screen and read attentively the "Software License" and "Readme". In "custom", you can select your operating system.

The installation program gives you further instructions.

If the message "Der Keyboard Kernel wurde noch nicht gestartet, ..., soll der Kernel jetzt gestartet werden?" (the keyboard kernel has not been started, ... do you want to start the kernel now?) appears when starting the program, first deinstall the ADDIREG program with ADDI-UNINSTALL and install ADDIREG anew.

### 7.3.2 Program description

#### **IMPORTANT!**

If you use one or several resources of the board, you cannot start the ADDIREG program.

The ADDIREG registration program is a 32-bit program for Windows NT 4.0 and Windows 95/98.

The user can register all hardware information necessary to operate the ADDI-DATA PC boards.

## **1 IMPORTANT!** Insert the ADDI-DATA boards to be registered before starting the ADDIREG program.

If the board is not inserted, the user cannot test the registration.

Once the program is called up, the following dialog box appears.

Board name	Base address	Access	PCI buz/device/(slot)	Interrupt	ISA DMA	More information		
Insert	ion		Edd				Giran	
lase address r	iame : In	temupt nam	e D	MA name:	<u>-</u>	Set	Concel	
Access mode:		terrupt :	ľ	MA channel	<u> </u>	Default	More	

#### Fig. 7-2: ADDIREG registration program

The table in the middle lists the registered boards and their respective parameters.

#### **Board name:**

Names of the different registered boards (e.g.: APCI-3120). When you start the program for the first time, no board is registered in this table.

1

#### **Base address:**

Selected base address of the board.

#### • **IMPORTANT!** The base address

The base address selected with the ADDIREG program must correspond to the one set through DIP-switches.

#### Access:

Selection of the access mode for the ADDI-DATA digital boards. Access in 8-bit or 16-bit.

#### PCI bus/device(slot):

Used PCI slot. If the board is no PCI board, the message "NO" is displayed.

#### Interrupt:

Used interrupt of the board. If the board uses no interrupt, the message "Not available" is displayed.

#### • **IMPORTANT!** The interrupt sel

The interrupt selected with the ADDIREG program must correspond to the one set through jumpers.

#### ISA DMA:

Indicates the selected DMA channel or "Not available" if the board uses no DMA.

#### More information:

Additional information like the identifier string (e.g.: PCI1500-50) or the installed COM interfaces.

#### **Text boxes:**

Under the table you will find 6 text boxes in which you can change the parameters of the board.

#### **Base address name:**

When the board operates with several base addresses (One for port 1, one for port 2, etc.) you can select which base address is to be changed.

#### **Base address:**

In this box you can select the base addresses of your PC board. The free base addresses are listed. The used base addresses do not appear in this box.

#### Interrupt name:

When the board must support different interrupt lines (common or single interrupts), you can select them in this box.

#### Interrupt:

Selection of the interrupt number which the board has to use.

#### DMA name:

When the board supports 2 DMA channels, you can select which DMA channel is to be changed.

#### **DMA channel:**

Selection of the used DMA channel.

#### **Buttons:**

### <u>E</u>dit <sup>1</sup>:

Selection of the highlighted board with the different parameters set in the text boxes.

Click on "Edit" to activate the data or click twice on the selected board.

#### Insert:

When you want to insert a new board, click on "Insert". The following dialog window appears:



#### Fig. 7-3: Configuring a new board

All boards you can registered are listed on the left. Select the wished board. (The corresponding line is highlighted).

On the right you can read technical information about the board(s). Activate with "OK"; You come back to the former screen.

#### Clear:

You can delete the registration of a board. Select the board to be deleted and click on "Clear".

#### <u>S</u>et:

Sets the parameterised board configuration. The configuration should be set before you save it.

#### <u>Cancel:</u>

Reactivates the former parameters of the saved configuration.

#### Default:

Sets the standard parameters of the board.

<sup>&</sup>lt;sup>1</sup> "x": Keyboard shortcuts; e.g. "Alt + e" for Edit

#### More information:

You can change the board specific parameters like the identifier string, the COM number, the operating mode of a communication board, etc... If your board does not support these information, you cannot activate this button. If you use the standard driver for Windows, you can select the COM number. If you use the ADDI-DATA driver, you can select the identifier string for each module.

Several options like "Module selection" and the different parameters can only be activated if the functions are available.

#### Save:

Saves the parameters and registers the board.

#### **<u>R</u>estore:**

Reactivates the last saved parameters and registration.

#### Test registration:

Controls if there is a conflict between the board and other devices. A message indicates the parameter which has generated the conflict. If there is no conflict, "OK" is displayed.

#### **Deinstall registration:**

Deinstalls the registrations of all board listed in the table.

#### **<u>P</u>rint registration:**

Prints the registration parameter on your standard printer.

Quit:

Quits the ADDIREG program.

#### 7.3.3 Registering a new board



#### **IMPORTANT!**

To register a new board, you must have administrator rights. Only an administrator is allowed to register a new board or change a registration.

- Call up the ADDIREG program. The figure 7-2 is displayed on the screen. Click on "Insert". Select the wished board.
- Click on "OK". The default address, interrupt, and the other parameters are automatically set in the lower fields. The parameters are listed in the lower fields.

If the parameters are not automatically set by the BIOS, you can change them. Click on the wished scroll function(s) and choose a new value. Activate your selection with a click.

- Once the wished configuration is set, click on "Set".
- Save the configuration with "Save".

• You can test if the registration is "OK".

This test controls if the registration is right and if the board is present. If the test has been successfully completed you can quit the ADDIREG program. The board is initialised with the set parameters and can now be operated.

In case the registration data is to be modified, it is necessary to boot your PC again. A message asks you to do so. When it is not necessary you can quit the ADDIREG program and directly begin with your application.

## 7.3.4 Changing the registration of a board

1

### **IMPORTANT!**

To change the registration of a board, you must have administrator rights. Only an administrator is allowed to register a new board or change a registration.

- Call up the ADDIREG program. Select the board to be changed. The board parameters (Base address, DMA channel, ..) are listed in the lower fields.
- Click on the parameter(s) you want to set and open the scroll function(s).
- Select a new value. Activate it with a click. Repeat the operation for each parameter to be modified.
- Once the wished configuration is set, click on "Set".
- Save the configuration with "Save".
- You can test if the registration is "OK". This test controls if the registration is right and if the board is present. If the test has been successfully completed you can quit the ADDIREG program. The board is initialised with the set parameters and can now be operated.

In case the registration data is to be modified, it is necessary to boot your PC again. A message asks you to do so. When it is not necessary you can quit the ADDIREG program and directly begin with your application.

### 7.3.5 Removing the ADDIREG program

The ADDI\_UNINSTALL program is delivered on the CD-ROM.

• Start the ADDI\_UNINSTALL program.

/ ADOI-DATA Uninstall program Version 0600/0103 ADDIREG UNIVERSALDRIVER . Select All ADDICOM PA100 PA1000 ADDI-DATA PA101 W. Clear All PA110 PA150 PA1500 PA1508 3 Bemove PA160 PA1610 PA200 PA2000 Exit PA2200 APCI1500 PA3000 PA302 **Deinstall Registration for AddiReg** 3 -PA310

Fig. 7-4: The ADDI\_UNINSTALL program

- Click on "Deinstall registration for AddiReg".
- Proceed as indicated until the complete removing of ADDIREG.
- You can also download the program from Internet.

## 7.4 Installing the drivers

The ADDI-DATA communication boards are operated as standard COM. They can thus be used with the Windows Standard driver "SERIAL COMMUNICATION in WIN32". Software examples are available on the CD-ROM.

1

## IMPORTANT! Do install the ADDIREG program first, before you install and

start any other applications.

## 7.4.1 Installation under DOS and Windows 3.11

- Copy the contents of PA732\16bit on a disk.
   If several disks are to be used, the directory content is stored in several subdirectories (Disk1, Disk2, Disk3...).
- Insert the (first) disk into a drive and change to this drive.
- Enter <INSTALL>.

The installation program gives you further instructions.

## 7.4.2 Installation under Windows NT/95/98

- Change to the CD drive; You find the software examples as follows:

#### Fig. 7-5: Installation of the examples under Windows NT/95/98



- Under PA732/winNT-9x/Disk1 start the set-up program "setup.exe" (double click).

Proceed as indicated on the screen and read attentively the "Software License" and "Readme".

The installation program gives you further instructions.

## 7.5 Questions and software downloads

Do not hesitate to visit us or e-mail your questions. Our Internet page is accessed: - per e-mail: info@addi-data.de or hotline@addi-data.de - per Internet : http://www.addi-data.de. or http://www.addi-data.com

#### Free download of standard software

You can download the latest versions of the standard software for the board **PA 732**, of ADDIREG and ADDI-UNINSTALL.

## 8 CONNECTION TO THE PERIPHERAL





Table 8-1: Pin assignment

Pin	Signal	Mode / Meaning
1	PG	Protection ground
2	TxD	RS 232 transmitted data
3	RXD	RS 232 received data
4	RTS	RS 232 request to send
5	CTS	RS 232 clear to send
6	DSR	RS 232 data set ready
7	SGND	RS 232 signal ground
8	DCD	RS 232 data carrier detect
20	DTR	RS 232 data terminal ready
22	RI	RS 232 ring indicator
24	Tx+	RS 422 transmit
23	Tx-	RS 422 transmit
17	Rx+	RS 422 received /RS 485 received
16	Rx-	RS 422 received / RS 485 received
14	RTS+	RS 422 request to send+*
13	RTS-	RS 422 request to send-*
21	CTS+	RS 422 clear to send+*
19	CTS-	RS 422 clear to send-*
10	GND isola	Isolated ground
11	+Tx-CL-DATA	CL transmitted data
12	-Tx-CL-DATA	CL transmitted data
18	+RCV-CL-DATA	CL received data
25	-RCV-CL-DATA	CL received data
9	Current source out 1	Current source out 1
15	Current source out 2	Current source out 2

\* **RS 422:** The signals on pins 13, 14, 19 and 21 are optionally available.

## 9 FUNCTIONS OF THE BOARD

## 9.1 Block diagram

### Fig. 9-1: Block diagram of the PA 732



## 9.2 I/O mapping

	IORD			IOWR				
Base +0	RECEIVER BUFFER			TRANSMIT REGISTER				
Base +1	INTERRUPT ENABLE REGISTER							
Base +2	INTERRUPT IDENTIFICATION REGISTER							
Base +3	LINE CONTROL REGISTER							
Base +4	MODEM CONTROL REGIS			STER RTS DTR				
Base +5	LINE STATUS							
Base +6	MODEM STATUS							
Base +7		IRQ TC	DATA DIR		TC- CLEAR	RD- EN	DATA DIR	
		D1	D0		D2	D1	D0	

#### Table 9-1: I/O mapping of the PA 732

You will find the meaning of the data bits for base + 7 in the following description.



### WARNING!

The board cannot work simultaneously in several operating modes. Please make sure to plug only the jumpers which are necessary for the respective functions!

## 9.3 RS232

## 9.3.1 Jumper settings

#### Mode without modem control signals (DTR, CTS, RTS, DCD, DSR):

- J14 set  $\rightarrow$  RS232 data receiver
- J21 not set The modem control signals are internally wired when J21 is not set: (DTR → DCD, DSR) (RTS → CTS)

#### Mode with modem control signals (DTR, CTS, RTS, DCD, DSR, RI):

- J14 set  $\rightarrow$  RS232 data receiver
- J13 on position  $K \rightarrow$  modem control signal CTS in RS232 mode
- J21 set → The input signals CTS, DCD, DSR, RI are controlled via the 25-pin SUB-D connector.

### 9.3.2 Wiring principle for RS232 mode



#### Fig. 9-2: Wiring for RS232 mode

### 9.4 RS422

#### 9.4.1 Jumper settings

#### RS422 mode without modem control signals (DTR, CTS, RTS, DCD, DSR)

- J15 set  $\rightarrow$  RS422 data receiver
- The modem control signals are internally wired when J21 is not set: (DTR → DCD, DSR) (RTS → CTS)
- J23 set in position P
- J18 set for releasing the RS422 sender

#### RS422 mode with modem control signals (CTS, RTS $\Rightarrow$ Option RC)

- J15 set  $\rightarrow$  RS422 data receiver
- J13 in position  $L \rightarrow$  modem control signal CTS in mode RS422 (Option RC)
- J21 set → The input signals RTS, CTS, DCD, DSR, DTR are controlled via the 25-pin SUB-D male connector. The signals DTR, DCD, DSR must be externally wired to the connector.
- J23 set in position P
- J18 set for releasing the RS422 sender

#### 9.4.2 Release of the R\$422 sender

If the board is connected to a network, the sender must then be blocked after having sent data. There are two ways to control the release of the sender via jumper J18 (see Fig. 9-3).

- RS422 sender permanently released (J18 on position N)
- The release of the sender can be programmed via the **DTR** bit (J18 on position M)

The **DTR** bit is the D0 bit of the modem control register on the address base + 4 of the USART.

- **DTR** bit =  $0 \rightarrow$  sender blocked (reset value)
- **DTR** bit =  $1 \rightarrow$  sender released

The **DTR** bit controls at the same time the hardware pin DTR of the USART.





Please make sure that the values of the data bits D1 - D7 remain when rewriting the register base+4!

### 9.4.3 Wiring principle for R\$422 mode



#### Fig. 9-4: RS422 wiring without modem control

Note: The control signals are to be wired on the board.

#### Fig. 9-5: RS422 wiring with modem control (Option RC)



\* The signals DSR, DCD and DTR must be wired in the connector.

#### **Terminal resistors for RS422**

In mode RS422, the reception lines are connected to defined levels via  $1k\Omega$  resistors. You can also insert a terminal resistor via jumper J5 (see Fig. 9-6), if the board is located at the end of the network.

- Terminal resistor 100 Ohm (J5 in position A)
- Terminal resistor 120 Ohm (J5 in position B)

To ensure a line interruption in RS422 mode, a logic has been implemented which allows the reversal of the input levels when the line is open. The setting is made via jump wire connections BR1 (Rx+) and BR2 (Rx-).



#### Fig. 9-6: Terminal resistor

At delivery the Rx+ und Rx- lines are not reversed (BR2 = 2, BR1 = 1). In order to reverse the input levels when the line is open, the jump wire connection must be set as follows:

BR2 = 1 and BR1 = 2

#### Fig. 9-7: Insertion of a terminal resistor in the CTS reception lines (Option RC)





## 9.5 RS485

### 9.5.1 Jumper settings

Mode without modem control signals only (RTS, CTS, DCD, DTR, DSR)

- J15 set  $\rightarrow$  RS485 data receiver
- The modem control signals are internally wired when J21 is not set: (DTR → DCD, DSR) (RTS → CTS)

### 9.5.2 Sender release

There are different ways for the user to release or block the RS485 sender via software. The control of the sender has to be pre-set via jumper J6 as follows:

- Control with DTR bit (bit D0 modem control register Base+4; J6 in position C)
   DTR bit = 0; → Sender blocked (reset value)
   DTR bit = 1; → Sender released
   Corresponds to the hardware pin of the USART
- Control with DATA DIR bit (bit D0 address base + 7; J6 in position D)
   DATA-DIR bit = 0; → Sender blocked (reset value)
   DATA-DIR bit = 1; → Sender released
   The DATA DIR bit can be read back on address base+7.
- Control with RTS bit (bit D1 modem control register base+4; J6 in position E) RTS bit = 0; Sender blocked (reset value) RTS bit = 1; Sender released Corresponds to the hardware pin of the USART



## Fig. 9-8: Setting of the sender release with the control signals DTR, RTS or DATA DIR via jumper J6

Please make sure that the values of the data bits D2 - D7 remain when rewriting the register base+4!

#### 9.5.3 Control of the receiver

There are two ways for the user to control the receiver via jumper J23.

J23 in position O → Control is made via RD-EN bit (bit D1, address base+7)
 RD-EN = 0 → Reception is possible (reset value)
 RD-EN = 1 → Reception is not possible

After reset,  $\mathbf{RD}$ - $\mathbf{EN} = 0$ . The system is in receiver mode.

- J23 in position P → Control is made via RTS, DTR or DATA DIR bit (depending on the position of jumper J6). With this setting, the sender and the receiver are reciprocally released. This means that:
  - if the sender is released, the receiver is blocked
  - if the sender is blocked, the receiver is released.



#### Fig. 9-9: Settings for the receiver release via J23

#### **Terminal resistors in RS485 mode**

In mode RS485, the reception lines are connected to defined levels via 1kOhm resistors. You can also insert a terminal resistor via jumper J5 (see Fig. 9-10) if the board is located at the end of the network.

- J5 in position A  $\rightarrow$  terminal resistor 100 Ohm
- J5 in position  $B \rightarrow$  terminal resistor 120 Ohm

To ensure a line interruption in RS485 mode, a logic has been implemented which allows the reversal of the input levels when the line is open. The setting is made via jump wire connections BR1 (Rx+) and BR2 (Rx-) See Fig. 9-10.



Fig. 9-10: Terminal resistor

At delivery the Rx+ und Rx- lines are not reversed (BR2 = 2, BR1 = 1). In order to reverse the input levels when the line is open, the jump wire connection must be set as follows:

BR2 = 1 and BR1 = 2



#### Fig. 9-11: Wiring for RS485

## 9.6 20mA current loop (TTY)

The board **PA 732** can be used as a current loop interface. It can send or receive data actively as well as passively.

You will find on the board one 20mA current loop source for the sender mode and one for the receiver mode.

### 9.6.1 Jumper settings

- J20 set
- J7 → 20mA current loop, preparation for data transmission See jumper settings The position of the jumper has to be adjusted to the peripheral of the current loop.
- J8 → 20mA current loop, preparation for data transmission See jumper settings The position of the jumper has to be adjusted to the peripheral of the current loop.
- The modem control signals are internally wired when J21 is not set: (DTR → DCD, DSR) (RTS → CTS)

### 9.6.2 Configuration of the current source

The current sources on the board are used to provide a constant 20mA current on the sender or the receiver line. In the passive mode, this constant current can also be provided by the device or the board on the opposite side.

Depending on the configuration, we speak of active transmission/reception or passive transmission/reception.

The selection occurs via the jumpers J16 (sender line) and J17 (receiver line). See Jumper settings

## 9.6.3 Wiring for 20mA current loop (TTY)

#### Active transmission/active reception



#### Fig. 9-12: Active transmission/active reception

#### Active transmission/passive reception





#### Passive transmission/active reception



#### Fig. 9-14: Passive transmission/active reception

#### Passive transmission/passive reception







### Fig. 9-16: Connection to a Siemens S5

## 9.7 Reference potential for the damping diodes

All input and output lines on the board **PA732** are protected against overvoltage via damping diodes located immediately after the connector to the peripheral.

- RS232: All lines (RTS, DTR, DSR, CTS, DCD, RI, TxD und RxD) are protected via TRANSIL damping diodes. Breakdown voltage = +/- 25V
- RS422: All lines are protected via TRANSIL damping diodes. Breakdown voltage = +/- 6,5V All lines are protected against short-circuits via PTC resistors.
- RS485: All lines are protected via TRANSIL damping diodes. Breakdown voltage = +/- 6,5V All lines are protected against short-circuits via PTC resistors.
- **20mA Current loop:** The current loops are protected via bi-directional TRANSIL damping diodes. Breakdown voltage : +/-26V

#### The user can select two reference potentials via jumper J9.

- J9 on pos. I → derivation of the interference voltage via secondary ground DC/DC converter
- J9 on pos. J → derivation of the interference voltage via pin 1 of the SUB-D connector

When adjusting the board this way, please make sure that the pin 1 of the 25-pin SUB-D connector is safely grounded externally.



#### Fig. 9-17: Selection of the reference potential for the damping diodes

## If pin 1 of the SUB-D connector is used for derivation of the interference voltage,

then the pin 1 of the connecting cable must be connected:

- to the shield of the cable as well as
- to the housing of the female connector of the cable

### 9.8 DMA mode

The DMA mode of the PC allows data exchange between the PC memory and the board via the hardware of the PC system in the background of running processes. Consequently, the board is assigned memory space of the PC which is structured as a FIFO memory. The data exchange is controlled by the board via 3 control signals. Three DMA channels are available to the user: DMA0, 1, 3.

For the selection of the DMA channel and the IRQ channel, see paragraph 5.2 Settings of the jumpers.

After the hardware configuration has been set, the DMA controller of the PC system has to be programmed. For that purpose, a software driver supplied with the board is available. Please make sure to use a free interrupt line with J4.

#### Description of the data bits relevant to the DMA mode on address base+7:

Reading of address base + 7, status bit **IRQ-TC** (bit D1 address base + 7)

 The IRQ-TC bit displays the status of a DMA transfer: IRQ-TC = 1 → DMA transfer is over IRQ-TC = 0 → DMA transfer is being done

Writing on the address + 7, control bit **TC-CLEAR** (bit D2 address base + 7):

 The TC-CLEAR bit is used in DMA mode to reset the interrupt flip-flop. TC-CLEAR = 1 → IRQ-FF reset TC-CLEAR = 0 → IRQ-FF not reset

Please make sure that the values of the data bits D0 to D1 of the address base+7 remain unchanged!

## **10 TROUBLE SHOOTING**

## **10.1** No communication

Should communication between the **PA 732** and your terminal not take place, then you should control the settings of the board (base address, interrupts, operating mode) as well as the wiring.

## 10.2 Reception of wrong data

In this case, please control following settings:

- The baud rate and the data format of the communication boards
- The base address of the **PA 732** and of the other boards also installed in the PC system. Several addresses might overlap.
- Interrupt setting

## 10.3 Transmission possible, but no reception

Please control the setting of the operating mode of the receiver (chapter 9). The wrong jumpers might be set, or the receiver might be blocked (by RS422, RS485).

## 11 STANDARD SOFTWARE

To install the port of the **PA 732** please use the standard drivers which are delivered with Windows NT 4.0 and Windows 95/98. You can read additional information about the Windows API functions for the settings and the use of the serial interfaces in the manual delivered with the board:

#### "SERIAL COMMUNICATION in WIN32".

Moreover you will find application examples in Delphi 2.0 and VC ++ 5.0.

## INDEX

ADDIREG 17-23 changing the configuration 22 installation 17 removing 23 base address 8, 12-13 block diagram 27 board component scheme 6 handling 3 insertion 14 options 5 slot 4 connector pin assignment 26 Current Loop 37-40 current source 37 jumper settings 11 current source 37 **DMA 43** jumper settings 12 EMC 4 functions of the board 27-43 Internet 25 jumper location on the board 7 settings 7-12 limit values 5 modem control signals jumper settings 11 operation mode Current Loop 11, 37-40 jumper settings 9 RS232 28 RS422 10, 29-33 RS485 10, 33-36

options 5 PC closing 15 minimum requirements 5 opening 14 peripheral 26 protection diodes reference potential 41 receiver control 34 jumper settings 10 reference potential 41 jumper settings 11 RS232 28 RS422 29-33 RS485 33-36 receiver control 34 sender release 33 settings 6-13 base address 8, 12-13 interrupt 8 jumpers 7-12 slot types 14 software delivery contents 16 installation 16 technical data 4-5 terminal resistor 32, 35 jumper settings 9 transmitter control 33 jumper settings 10 user 2