Tutorials

About the Tutorials

This chapter consists of seven tutorials. You have selected the one that is highlighted in red:

- Tutorial 1 Fundamentals
- Tutorial 2 Working with Channels
- Tutorial 3 Triggering
- Tutorial 4 Working with Special Modes
- Tutorial 5 Working with Subchannels
- Tutorial 6 Arbitrary Waveform Generator
- Tutorial 7 Using the Graphical Waveform Editor

Each section is a self-contained tutorial. If you are new to GageScope[®], it is recommended that you do the tutorials in the order they are presented, as each section assumes you have gone through the previous material.

Tutorial 4: Working with Special Modes

This tutorial deals with three special modes available in GageScope[®]:

- Persistence Mode page 2
- SuperRes Mode page 11
- Multiple Record Mode page 17
- Scope Mode page 34
- Decimation Mode page 43

Persistence Mode

The **Persistence** setting allows the user to control the persistence of the signal display in the Display Window. By default, the signal does not persist in the Display Window. However, with the special Persistence Controls in GageScope[®], you can specify any degree of persistence that you wish, from none to infinite.

The **Persistence** button is located in the Settings tab of the Display Control.

General Settings	Persistence
Grid Color Persistince - Trigger Lines XAxis Color none Zero Lines Zero Lines	Button
CS2125:YT1	Infinite — Persistence Checkbox

Set Persistence to Infinite

- Make sure you are in Continuous Capture mode (the button in the Toolbar should be "pressed in.")
- 2 By default, Persistence is disabled. The button underneath Persistence reads **None**. To enable persistence, click on **None**.

Gene	ral S	Settings	
Grid	Color	Persistence -	Trigger Lines
XAxis	Color	none	Zero Lines
Y Axis	Color	🛛 🗆 Infinite	Back Color
	52125:`	× ۲۱۱ [

3 The Persistence field appears.

Grid	Color	Persistence -	Trigger Lines
< Axis	Color	0.52 ÷	Zero Lines
Y Axis	Color	🛛 🗖 Infinite	Back Color

4 Click on the **Infinite** checkbox for infinite persistence. This is equivalent to clicking the **Overdraw Mode** button in the toolbar.

Grid	Color	- Persistence -	Trigger Lines
X Axis	Color		Zero Lines
Y Avis	Color	🔽 Infinite	Back Color

5 Our signals are now persisting on the screen. You may notice the signals getting slightly thicker.

👪 GageScope for Windows - [System1:Display	1]	CaCe - BX
Eile View Capture Iools Window Help		_B×
# # X ← © S ← 은 M ← X ←	; Q Q ≋ <mark>∧</mark> Ø 9 49 ⇔ 5 8 bits y ≅ ⊟ 国	
Info View III X Name Value Ch 1 ✓P Ch 2 Ch 2		
Watch1 For Help, pre	ess F1	
CS2125 Trigger Depth Averaging Ch 1 Level 0.00 mV Patern. System1	General Settings Grid Color., Persistence Trigger Level XAxis Color., IF Infinite Back Color Display1	CS Input Trace Vert. Scale 1VZd ∩ Method Min Max ▼ 2 All ← Ch1 ← Ch2

However, to truly see Persistence at work, we will change some settings that will affect the signal display.

Change the Timebase to 1 us/d

1 Click on the General tab of the Display Control to access the Timebase buttons.



² Click on <u>once to change the timebase to **2us/d**</u>. Watch how your signal display changes—the old signal persists while the new signal is being displayed.



³ Click on <u>again so that the timebase becomes 1us/d</u>. The new signal will be displayed along with the previous two signals.

🖀 GageScope for Windows - [System1:Display]]	CaCz - B ×
Eile ⊻iew Capture Tools Window Help		_ B ×
¥ (+ ++ 11 C < ++1 \$\$ \$ \$ \$ \$ \$ \$		
Info View 125 MS/s Name Value Ch1 feast Ch2 Ready Match1 For Hep, pre	Timebase: 1us M.Pos: 0.0 s	
CS2125 Trigger Depth Averaging Ch1 Level 0.00 mV Pattern. System1	General Settings Timebase □us/d □us/d □us/ch1 □us/ch2 □us/d □us/	CS Input Trace Vert. Scale nu Connect Dots Method Min Max V P All P Ch 1 P Ch 2

Erase the Display

1 An **Erase Display** button becomes available in the toolbar when Persistence mode is turned on.



2 Click on 🖉 to clear the previous signals. The latest signal with a timebase of 1us/d is the only one in the Display Window now.



Set Persistence to 5 seconds

1 Click on the **Settings** tab of the Display Control so that it is again in front.



2 Turn off Infinite Persistence by clicking on the checkmark next to Infinite.



3 Turning off Infinite Persistence turns off Persistence altogether. To enable Persistence again, click on **None**.

Grid	Color	Persistence -	Trigger Lines
< Axis	Color	none	Zero Lines
/ Axis	Color	🗖 Infin	Back Color

4 To change the length of time that the signal will persist on the screen, you can click on the **Increment Up** and **Increment Down** buttons.



5 Click and hold the **•** button until the Persistence is set to **5.0s**.

🖀 GageScope for Windows - [System1:Display]]	
		_ & ×
😂 📓 👙 🔿 🛃 🝩 🌦 🛪! 👯 🏋	‡ ૧. ૨. ≋ ∧ ૭	
🛉 🚧 fixi 🚼 114 🕨 🖄 11 144 🦗	i 🖧 😂 🗲 🛚 🗖 🗖 🗖 🗖	
Info View <u></u> Name Value Ch₁ ✓↔ Ch2		
Watch1 / For Help ore:	Timebase: 1us M.Pos: 0.0 s	
CS2125 Trigger Depth Averaging Ch1 Level 0.00 mV F Pattern. System1	General Settings Grid Color Persistence	Vert Scale Vert Vert Scale Vert Scale Vert Vert Vert Vert Vert Vert Vert Vert

6 Now our signals will persist, but only for 5 seconds. To test this, we will again go to the **General** tab of the Display Control.



7 Change the Timebase to **2us/d** by clicking



8 You will notice that the old signal briefly persists on the screen.



9 The display is erased after a short time, so that only the latest signal is preserved.

🜃 GageScope for Windows - [System1:Displa	y1]	GaGe - BX
Eile ⊻iew Capture Tools Window Help		×
*** # ! × & © 5 ← 1 ≧ E & C *** ** C = **1 5 ≈1 ∞ → →	\$ Q Q ≈ ^ Ø 4 4 A S bits y 🗂 🗆 🖬	
Info View III III III III III IIII IIII IIII I	Timebase: 2us M.Pos: 0.0 s	
CS2125 Trigger Depth Averaging 1	General Settings	CS Innut Trace
Ch1 Level 0.00 mV	Timebase 2us/d 2us/d ♥↓Chanel Name ♥↓Chanel Name ♥↓Chanel Name	Vert. Scale
📌 System1	Display1	

Setting the Persistence to 5 seconds has the same effect as clicking the **Erase Display** button every 5 seconds.

Turn Persistence Off

1 To disable Persistence Mode, go back to the **Settings** tab of the Display Control. Click on the **Persistence** field so that it reads **None**.



2 To get ready for the next part of the tutorial, change the Timebase back to **5 us/d** (click on which in the **General** tab of the Display Control).

SuperRes Mode

SuperRes Mode allows an averaging window to be defined within a single acquisition. All samples within the averaging window are accumulated, resulting in an effective increase in the sample bits. The averaging window is then shifted, over the current acquisition, by its width and the same averaging process is performed repeatedly.

SuperRes allows you to specify the desired "Effective Resolution." For example, you can specify 12 bit resolution even if you are using the 8 bit CompuScope 8500. GageScope[®] will automatically perform digital filtering (averaging of oversampled data) to enhance the effective resolution at the expense of sample rate.

For example, in order to provide 12 bits for the CompuScope 8500 (an increase of 4 bits), GageScope[®] has to average $2^4 = 16$ adjacent points, hence reducing the sample rate by a factor of 16. This means that instead of 500 MS/s, the sample rate will be 500/16 = 31.25 MS/s.

Note

• The effective resolution mentioned here is **not** the same as Effective Number of Bits (ENOB). ENOB is a measurement of the Signal-to-Noise Ratio.

SuperRes is located in the CS tab of the System Control.



Enable SuperRes Mode

Make sure you are in Continuous Capture mode (the button in the Toolbar should be "pressed in").

2 Click on the CS tab of the System Control to bring it to the front.

CS2125 Trigger	Depth
Ch 01	Level -54.7 mV
1	Ť
Pattern.	
💉 CS2125	

3 Click on the **SuperRes** checkbox to enable SuperRes mode.

Sample rate: 125 MS/s 💌
SuperRes Single Dual

You can also click the SuperRes button in the toolbar (it should be "pressed in").

4 Notice that **SuperRes** appears in the upper left of the Display Window, next to the sample rate.

🖀 GageScope for Windows - [System1:Display	4]	GgCe - B×
Eile View Capture Tools Window Help		<u>_ 8 ×</u>
*** * × ← @ ਯ ← 은 은 일 61 אי אי ע ⊂ ∢ אין א א <i>ן א</i> א	; Q, Q, ≋ ∧ // G +2, ⇔ <mark>// S bits ▼</mark> ☎ ⊟ ■	
Info View I25 MS/s Name Value 8 bit Ch 1 Ch 2 Ready Image: Second Secon	SuperHes	
CS2125 Trigger Depth Averaging SamperRet: 125 MS/s ▼ SuperRet: Single Dual	General Settings Timebase SusJd ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	CS Input Trace Vert. Scale Vert. Vert. Scale Vert. Vert. Ver

Increase the Bit Resolution by 6 or 7 Bits

- 1 We will now increase the Bit Resolution of the signal displayed on the screen.
 - 8 bit CompuScope cards: Increase the bit resolution to 15 bits
 - 12 bit CompuScope cards: Increase the bit resolution to 18 bits

To increase the bit resolution, click on the **Up Increment** button **I** on the CS tab of the System control.

CS2125 Trigger Depth
Sample rate: 125 MS/s 💌
SuperRes Single Dual
📌 CS2125

You can also click on the SuperRes drop-down menu in the toolbar.

2 Note that when you increase the bit resolution, the sample rate decreases. For instance, we have raised the bit resolution on our CS2125 to 15 bits and our sample rate has decreased to 977 kS/s from 125 MS/s. You will not be able to increase the sample rate until you decrease the bit resolution again.

CS2125 Trigger Depth	
Sample rate: 977 kS/s 💌 SuperRes Single Dual	
💉 CS2125	1

3 With such a comparatively low sample rate, our signal display becomes jagged.



When the sample rate is low, the CompuScope card is acquiring fewer sample points per second. With fewer points available for building a representation of the signal, the resulting waveform looks jagged. Keep in mind that this illustration uses a slow capture rate. The true power of SuperRes is more evident with a faster sampling rate; while the waveform remains mostly unchanged, the signal to noise ratio improves dramatically thanks to the increased resolution of the acquisition.

Decrease the Bit Resolution by 2 Bits

1 Decrease the bit resolution by two bits by clicking the **Down Increment** button

CS2125 Trigger Depth
Sample rate: 977 kS/s 💌
SuperRes Single Dual
Ŕ
💉 CS2125

2 Notice that GageScope[®] automatically raises the sample rate to the maximum rate corresponding to the selected bit resolution—in our case, the sample rate rose to 3.91 MS/s when we decreased the bit resolution to 13 bits.



The signal looks less jagged than before, since more samples are being acquired per second.

Disable SuperRes Mode

1 To disable SuperRes mode, click on the **SuperRes checkbox** in the CS Input Tab (so that it is unchecked), or click on **S** in the toolbar (so that it is not pressed in).

CS2125 Trigger Depth
Sample rate: 977 kS/s 💌
SuperRes Single Dual
K 15bit 🗧
-14
📌 CS2125

2 The bit resolution has been returned to normal, and the sample rate is now at its maximum value for dual channel mode.



Multiple Record Mode

Multiple Record Mode takes advantage of the CompuScope card's deep memory buffers by allowing the hardware to stack captures in on-board memory, so that many small acquisitions can occur in a very short amount of time, with near-zero re-arm time. This feature is invaluable in applications in which trigger events are happening rapidly or unpredictably and A/D down-time must be minimized.

When Multiple Record Mode is enabled, the CompuScope card looks for a trigger event, acquires post-trigger data, then automatically re-arms itself to look for another trigger event. Data collected from each successive acquisition is "stacked" on top of the previous acquisition until the on-board buffer fills up.

For example, if a post-trigger depth of 1024 points is specified, the first acquisition stores data in addresses between 0 and 1023, the next acquisition from 1024 to 2047, and so on until the buffer is full.

Important Notes

- The number of records you can capture will depend on the amount of on-board memory your CompuScope card has, as well as other settings, such as the post-trigger depth and channel mode.
- With all currently available CompuScope cards, you can only capture post-trigger data in Multiple Record mode. When you click on the **MulRec** button, pre-trigger capture is disabled.
- Multiple Record Mode comes as a standard feature or as an option on most CompuScope cards, but is not available on the CompuScope LITE. If your CompuScope card does not have this capability, the **MulRec** button will not be available.

CS8500 Trigger Depth	
Total: 2 M Smpl 💌 Fine	
PreTrig 4096 - Auto 10.0 ms	M D' I
PostTrig 4096 MulRec	/Multiple Records
	(Currently
💉 CS8500 💉 CG1100	Disabled)

The Multiple Record setting is located in the Depth tab of the System Control.

Perform a Multiple Record Capture

- Make sure you are in Continuous Capture mode (the button in the Toolbar should be "pressed in").
- 2 Click on the **Depth** tab of the System Control to access the Multiple Record controls.



3 Click on the **MulRec** button to enable Multiple Record Mode. Multiple Record Mode is enabled if its button is pressed in.

CS2125 Trigger Depth	
Total: 130944 Fine Units: Smpl 💌	
Pre Trig. 0 🗧 Normal 10.0 ms	
Post Trig. 4096 🕂 MulRec 31	Multiple Record now enabled
💉 CS2125	

4 GageScope[®] automatically captures the post-trigger data for as many records as possible, depending on the current channel mode, sample rate, and post-trigger depth settings.

🔚 GageScope for Windows - [System1:Dis	play1]	
Eile ⊻iew <u>C</u> apture <u>I</u> ools <u>W</u> indow <u>H</u> elp		_B×
🈂 📓 👙 🔿 🛃 🝩 🌤 🗶 🖡	1: ‡ ૨ ૨ ≋ ∧ ૭	
الا ک ♦ کا ا	🖌 🎸 🗁 💈 🕅 🔽 🗖 🔳	
Info View IN 125 M	S/s	
Name Value	••••••••••••••••••••••••••••••••••••••	\wedge \wedge \wedge
0.1	↓	
10		
31		
	· · · · · · · · · · · · · · · · · · ·	╷╴┎┿╾┑╴┇╾╾┑╴┇┍╼╼┧┇╴┏╼╼┪
Lh 2 1 of		
31	÷	
	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·
	ady Timebase: 5us M.Pos: 0.0 s	
For He	p, press F1	
CS2125 Trigger Depth Averaging	General Settings	CS Input Trace
Total: 130944 Fine Units: Smpl -	Timebase Channel Name	Vert. Scale
Pre Trig. 0 Auto 10.0 ms	5us/d	1V/d 1Uconnect Dots Method Record
Post Trig. 4096 + MulRec 31		<u>Min Max</u> 1 🕂
System1	Display1	

The number of records will be reflected in the Display Window underneath the channel number at the left. For example, if 31 records are captured as in our example, you will see "1 of 31" displayed underneath "Ch 1."

5 While you are performing a Multiple Record acquisition, you may briefly see the message "Transferring" in the Status bar.

Transfering	Timebase: 10us	M Post 50 Que
rransiciniy	TIMEDase. Tous	M.F.US. JU.UUS

This means that GageScope[®] is transferring data from the CompuScope board to the internal buffers of the application.

Scroll Through the Multiple Record Data via the Toolbar

1 To see more of your Multiple Record data, click the **Trigger Left Align** button in the toolbar.



2 You should now be able to see the entire record.

GageScope for Windows - [System1:	:Display1]	
Eile ⊻iew <u>C</u> apture <u>I</u> ools <u>W</u> indow <u>I</u>	<u>⊣</u> elp	_ <u>_</u> X
>> × < IN IN IN IN IN IN	; 1; ; Q Q ≋ ∧ // ₩ K K ⊖ 5 bits	
Info View IX	5 M5 /s 1	
Watch1 / For	Ready Timebase: 5us M.Pos: 25.0us Help, press F1	
CS2125 Trigger Depth Averagin Total: 130944 Fine Units: Smpl Pre Trig: 0 Auto 5:00 e Post Trig: 4096 H MulRec 31	g General Settings Timebase Channel Name Sus2d ⊄ ⊕ Ch1 ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	input Trace art. Scale Trace Incoment Dats Method Min Max T All Connect Dats Method Min Max T All Connect Dats Method Metho

3 Use the **Go to Next Record** button in the toolbar to scroll through your records one by one.



4 Beside Ch 1 and Ch 2 in the Display Window, you can watch the record counters increase by one with each click.

GageScope for Windows - [System1:Display	1]	GaCa Fax
Eile View Capture Iools Window Help		_ B ×
😂 📓 🥞 🔿 🔂 🤹 🛪 🗶 😭	🕽 🔍 🔍 🎘 🔿	
🛉 🕪 🖬 🙀 🕪 🖕 🙀 🗰	9 🖌 🖨 🗳 🛚 bits 🔽 🖾 🗖 🖬	
Info View ⊥ ≤ 125 MS/s Name Value Ch1 ✓=> 6 of 31 ≤ S S		
Ch 2 6 of 31 Watch1 / For Help, pr	T T Timebase: 5us M.Pos: 25.0us	
CS2125 Trigger Depth Averaging Totat 130944 Fine Units Smpl V Pre Ting 0 2 2 Auto 5.00 s Post Ting 4096 W MuRec 3 System1	General Settings Timebase Sus/d Sus/d Display1	Vert. Scale Vert. Vert. Scale Vert. Vert. Scale Vert. Vert.

5 Click the **Go to Previous Record** button in the toolbar to scroll backward through your records until you get back to Record 1.

	€€	₽	ڪ	11	It h
--	----	---	---	----	------

Scroll Through the Multiple Record Data via the Record Counter

1 Select the **Trace** tab in the Channel Control if it is not already in front.



2 Use the **I** and **I** buttons to perform the same function as the **Go to Next Record** and **Go to Previous Record** buttons on the Toolbar.



3 With these buttons, you can cycle through the records of all channels at once (if the All Channels Tab is current), or through the records of individual channels (if an individual channel tab is current).

Click on the Ch 1 tab of the Channel Control.

CS Input	Trace
-Vert. Scale	1 Connect Dots Invert
1V/d	Method Record Min Max I
<mark>~ ∧∥ </mark> ~	- Ch 1 4- Ch 2

4 Use the Record Counter to go to **Record 10** of Channel 1.



5 Now you are viewing Record 10 of Ch 1, while Ch 2 is still displaying Record 1.

🖀 GageScope for Windows - [System	1:Display1]	CaCe - B×
Eile View Capture Tools Window	Help	_ & ×
!× ⇔ © 5 ← ≗ ⊠ ≤ א וו כ ∢ או 5 א א ש	[; 1; 1] @ Q ≋ ∧ ∅ • ₩ 4; 4; ⊖ 5 855	
Info View II si Name Value	25 MS/s h1 /s h2 n T	
Watch1 F	Ready Timebase: 5us M.Pos: 25.0us or Help, press F1	
CS2125 Trigger Depth Average Totat 130944 Fine Units Sm PreTing D Auto 5.00 Post Trig 4095 MuRec 31 System1	ing General Settings CS Inp pI ▼ 5us/d ♥ ℃ Ch 1 ♥ ℃ Ch 2 ♥ Display1	ut Trace Drawing cale Position Position Position Percent Record 10

Set all Records to Record 1 via the Toolbar

1 Set all channels to the first record with the **I**III button in the toolbar.



Save Channel 1 to Individual Files

1 You can save a Multiple Record channel just as you would any other channel. However, there are a few options available for saving Multiple Record files which are not available with normal acquisitions. In this section, we will be saving each record in the acquisition to a separate file in one step.



2 The Save Channel dialog appears.



3 In the File Name field, type **mulrec.sig**.

Save Channe	l to File		? ×
Save jn:	🔁 Signal Files	-	<u>ĕ</u>
Am_sig.sig Am_sweep. Chopsine.si Dim_sine.si Frmstereo.si	isig Elitch.sig isig El Half_am.sig ig El Her_bone.sig ig El Sawtooth.sig ig El Sine.sig ig El Sinnoisy.sig	■) Sqr_wave.sig ■) Triangle.sig	
File <u>n</u> ame:	mulrec.sig		<u>S</u> ave
Channel:	Ch 1		Split MulRec
🗖 Save visib	ble portion of the channel		

4 Ch 1 should already be selected in the Channel field. If it is not, select it from the dropdown menu.

Save Channel to F	ile		? ×
Savejn: 🔂 S	ignal Files	-	<u> </u>
Am_sig.sig Am_sweep.sig Chopsine.sig Dim_sine.sig Fmstereo.sig Frqsweep.sig	Glitch.sig Half_am.sig Half_am.sig Her_bone.sig Sawtooth.sig Sine.sig Sinnoisy.sig	■) Sqr_wave.sig ■) Triangle.sig	
File <u>n</u> ame: mulre	c.sig		<u>S</u> ave
Save as type: Gage	Scope signal file(*.sig)	•	Cancel
Channel: Ch 1	•		🗖 Split MulRec
Save visib Ch 1 Ch 2	el l		

5 To save each record in the acquisition to a separate file, check the **Split MulRec** checkbox.

Save Channe	el to File		? ×
Save jn:	🔄 Signal Files	-	
Am_sig.sig Am_sweep Chopsine. Dim_sine.s Frastereo.s Frastereo.s	9	Sqr_wave.sig Triangle.sig	
File <u>n</u> ame:	mulrec.sig		<u>S</u> ave
Save as type:	GageScope signal file(*.sig)	•	Cancel
Channel:	Ch 1 💌		Split MulRec
🗖 Save visi	ible portion of the channel		

6 Click Save.

• Load one of the Saved Records to Ch 3

1 You can also load a Multiple Record channel as you would any other channel—by clicking in the toolbar.

2 The Load Channel dialog appears.

Load channel				<u>?</u> ×
Look jn: 🛛 🔂 Sig	gnal Files	-		Show Preview
Am_sig.sig	🖻 Glitch.sig	🗐 mulrec03.sig	🖻 mulrec09.s	
Am_sweep.sig	🗐 Half_am.sig	🗐 mulrec04.sig	🗐 mulrec10.s	
🖻 Chopsine.sig	🗐 Her_bone.sig	🖻 mulrec05.sig	🔳 mulrec11.s	
Dim_sine.sig	🔊 mulrec00.sig	🖻 mulrec06.sig	🔳 mulrec12.s	
🔳 Fmstereo.sig	🔳 mulrec01.sig	🖻 mulrec07.sig	🔳 mulrec13.s	
Frqsweep.sig	🔊 mulrec02.sig	🖻 mulrec08.sig	🔳 mulrec14.s	
	-			
•			•	
File <u>n</u> ame: *.sig			<u>O</u> pen	
Files of type: Gage	Scope signal file(*.sig)	-	Cancel	

Notice that since we selected **Split MulRec** when saving our Multiple Record acquisition, and in our example there were 31 records in the acquisition, we now have 31 files named "mulrecxx.sig," where xx is a suffix attached by GageScope[®], beginning at 00.

3 Click on the first of these files to select it, and then click Open.

Load channel				? ×
Look jn: 🔄 Signal Files	- E	<u> * </u>	Show Preview	
Am_sig.sig Glitch.sig Am_sweep.sig Am_sweep.sig Chopsine.sig Dim_sine.sig Frastereo.sig Frastereo.sig Frastereo.sig Frastereo.sig	mulrec03.sig mulrec04.sig mulrec04.sig mulrec05.sig mulrec06.sig mulrec07.sig mulrec08.sig	mulrec09.s mulrec10.s mulrec11.s mulrec12.s mulrec13.s mulrec14.s		$\sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{i=1}^{n} \sum_{j=1}^{n} \sum_{i$
File name: mulrec00.sig		<u>O</u> pen	Data: Depth:	8 bit 4096 smpl
Tragescupe signal file(.sig)		Lancel	Hecords:	31

4 Our signal file has been loaded as Ch 3, in between Ch 1 and Ch 2.

GageScope for Windows - [System1:Display1]	
Eile View Capture Iools Window Help	_ <u>8</u> ×
😂 🖬 👙 ⇒ 🧟 💩 🛪 🕼 🐩 ‡ 🍳 Q 🔅 ∧ 🥒	
f≈ ¼ fx 🚼 III > ⊃ III III > ∦ 🔏 😫 🖨 😏 8 bits 🝸 🕾 🔳	
Info View I 25 MS /s Name Value Info Value I 25 MS /s Ch 1 Ch Info Info S1 Info Info In	
rs2125 Trinner Denth Averann 1 General Settions 1 Truss 1 D	i INUM I
Control (1300544) Fine Units: Smpl v Sterring Sterring Vert. Scale Pre Ting Image: MulRec 31 Image: Weight 1 Image: Weight 1 Image: Weight 1 Vert. Scale Image: Weight 1 Image: Weight 1 Vert. Scale Image: Weight 1 Image: Weight 1 Image: Weight 1 Vert. Scale Image: Weight 1 Image: Weight	Position Position Position Record Ch1 Q Ch2 PA Ch 3

5 Hide Ch 3 by clicking the checkmark next to it in the Channel List (in the General tab of the Display Control).

General	Settings	
Timebase	Channel Name	
5us/d	🗹 🚭 Ch 1	
\sim \sim	🗹 🔂 Ch 2	
🔜 Display1		

Look at All Records of Channel 1 Simultaneously

1 Up to now, we have been viewing one record at a time. GageScope[®] also allows you to view all records at once.

Click on the Ch 1 tab of the Channel Control to bring it to the front again.



2 Click with the left mouse button in the **Record** field and press the Backspace to erase the value that's there. Then type **0** (zero).

CS Input	Trace	Drawing
Vert. Scale	F	osition
1V/d	[∙] 0 ∼	
<mark>≁ ∧∥ </mark> ٩	<mark>- Ch 1</mark>	≁ Ch2

3 Press Enter. The 0 will change to **All**.



4 The display will now show all of your records at once. To the left of the slope icon and below "Ch1" on the screen below, notice the message "All of 31," indicating that all 31 records are being displayed.

Eile View Capture Tools Window Help	<u>_ 8 ×</u>
ڬ 🖬 👙 ⇒ 🔁 🕸 🌥 🛪! [; *]; ‡] ⊕, ⊝,	š 🔨 🥏
לא גא לא אין אין אין אין אין אין אין אין אין אי	8 bits 🔽 🔚 🔳
Info View Image: Second s	
Watch1 For Help, press F1	
CS2125 Trigger Depth Averaging General Total: 130944 Fine Units: Smpl v Preffing 0 Auto 5.00 s Post Trig, 4096 MulRec 3	Settings Channel Name Channel Name Channe

Beneath the start of each record in the signal, its record number is displayed.

Note that you are still seeing only one record of Ch 2. If you wish to see all records of both channels, you can click the **All** tab in the Channel Control and type 0 in the Record Counter, followed by Enter.

5 Increase the timebase by clicking on <u>w</u> in the **General** tab of the Display Control.



6 This allows you to see more records.

🖀 GageScope for Windows - [System1:Display	1]	
Eile ⊻iew Capture Iools Window Help		×
20 20 4 10 10 10 10 10 10 10 10 10 10 10 10 10	; @ @ ≋ ∧ ∅	
	9 🕂 🏳 🖨 🕹 🛽 🖬 🔽 🗖	
Info View IIX 125 MS/s Name Value		
<i>C</i> ≉	ΑΛΛΛΛΛΛΛ	
Ch 1 All of All of 31	$[\lor \lor $	
		IIII
Ch 2 1 of 31		
	Т	-
Baad	Timehana 10m M Dear 50.0m	
Watch1 For Help, pre	sss F1	
CS2125 Trigger Depth Averaging	General Settings	CS Input Trace Drawing
Total: 130944 Fine Units: Smpl 💌	Timebase Channel Name	Vert. Scale Position
Pre Trig. 0 Auto 5.00 s		
Post Ing. 14096 MulHec 31		
💉 System1	Display1	

Save All Channel 1 Records to One File

- 1 Now that we are viewing all of Channel 1's records at once, we can also save all of the records to one file. This is only possible when **All** is displayed in the Record Counter for the channel you wish to save.
- 2 Click Save Channel **M** in the toolbar.

3 The Save Channel dialog appears.

Save Channel	to File		? ×
Save in:	🔁 Signal Files	-	* 📰 🏛
Am_sig.sig Am_sweep.s Chopsine.sig Dim_sine.sig	폐 Glitch.sig sig 폐 Half_am.sig g 폐 Her_bone.sig g 폐 mulrec00.sig	데 mulrec03.sig 데 mulrec04.sig 데 mulrec05.sig 데 mulrec06.sig	mulrec09.s mulrec10.s mulrec11.s mulrec12.s
Finstereo.sig Frqsweep.sig	n 폐 mulrec01.sig g 폐 mulrec02.sig	폐 mulrec07.sig 폐 mulrec08.sig	mulrec13.s mulrec14.s
File <u>n</u> ame: [Save as <u>t</u> ype: [<mark>*.siq</mark> GageScope signal file(*.sig)	•	<u>S</u> ave Cancel
Channel: [Ch 1		🗖 Split MulRec

4 In the File Name field, type **allrec.sig**.

Save Channel to) File		? ×
Savejn: 🧲	Signal Files	•	
🖻 Am_sig.sig	🖻 Glitch.sig	🖻 mulrec03.sig	🖻 mulrec09.s
📕 🖻 Am_sweep.sig	🔳 Half_am.sig	🖻 mulrec04.sig	🔳 mulrec10.s
🖻 Chopsine.sig	🔳 Her_bone.sig	🔳 mulrec05.sig	🔳 mulrec11.s
🔳 Dim_sine.sig	🔳 mulrec00. sig	🖻 mulrec06.sig	🔳 mulrec12.s
🔳 Fmstereo.sig	🖻 mulrec01.sig	🖻 mulrec07.sig	🔳 mulrec13.s
🖪 Frqsweep.sig	🖻 mulrec02.sig	🔳 mulrec08.sig	🔳 mulrec14.s
•			4
File <u>n</u> ame: all	rec.sig		<u>S</u> ave
Save as type: G	ageScope signal file(*.sig)	•	Cancel
Channel: Cł	n 1 💌		🗖 Split MulRec
🗖 Save visible j	portion of the channel		

5 Ch 1 should already be selected in the Channel field. If it is not, select it from the dropdown menu.

Save Channel	to File		? ×
Save in:	🔁 Signal Files	- 1	*
Am_sig.sig	🖻 Glitch.sig	🖻 mulrec03.sig	🖻 mulrec09.s
Am_sweep.:	sig 📕 Half_am.sig	🖻 mulrec04.sig	🖻 mulrec10.s
📕 🖻 Chopsine.sig	g 📕 Her_bone.sig	🖻 mulrec05.sig	🖻 mulrec11.s
📕 🖻 Dim_sine.sig) 🔟 mulrec00.sig	🖻 mulrec06.sig	🖻 mulrec12.s
📕 🖻 Fmstereo.sig) 🔟 mulrec01.sig	🖻 mulrec07.sig	🖻 mulrec13.s
📕 🖻 Frqsweep.si	g 🛛 🖻 mulrec 02. sig	🖻 mulrec08.sig	🖻 mulrec14.s
			Þ
File <u>n</u> ame:	allrec.sig		<u>S</u> ave
Save as type:	GageScope signal file(*.sig)	•	Cancel
Channel:	Ch 1		🔲 Split MulRec
🗖 Save visib	All Ch 1 de la ch Ch 2 de la ch		

6 Click Save.

• Load the All Records File to Ch 4

- 1 Click 😂 on the toolbar.
- **2** The Load Channel dialog appears.

Load channel			? ×
Look jn: 🔄 Signal Files	•		Show Preview
🖬 allrec.sig 📰 Frqsweep	sig 🔳 mulrec02.sig	🔊 mulrec08.s	
Am_sig.sig 🛛 🖾 Glitch.sig	📕 mulrec03.sig	🖳 mulrec09.s	
Am_sweep.sig 🛛 🗐 Half_am.s	ig 🔄 🔟 mulrec04.sig	🛋 mulrec10.s	
🛛 🖻 Chopsine.sig 🔹 🖻 Her_bone	.sig 🛛 🖻 mulrec05.sig	🖻 mulrec11.s	
Dim_sine.sig 🛛 🖬 mulrec00.	sig 🔳 mulrec06.sig	🖻 mulrec12.s	
Finstereo.sig mulrec01.	sig 🔲 mulrec 07. sig	mulrec13.s	
		_	
		F	
File <u>n</u> ame: <mark>*.sig</mark>		<u>O</u> pen	
Files of type: GageScope signal file	:(*.sig)	Cancel	

3 Along with our multiple **mulrecxx.sig** records, there is also an **allrec.sig** file. Click on **allrec.sig** to select it, and then click **Open**.

Load channel				? ×
Look jn: 🔄 Signal Files	- E (* 📰 🏛	Show Preview	
Am_sig_sig_ Am_sig_sig_ Am_sig_sig_ Am_sweep.sig Am_s	mulrec02.sig mulrec03.sig mulrec03.sig mulrec04.sig mulrec05.sig mulrec06.sig mulrec07.sig	mulrec08.s mulrec09.s mulrec10.s mulrec11.s mulrec12.s mulrec13.s		A
File name: allrec.sig Files of type: GageScope signal file(".sig)	×	<u>O</u> pen Cancel	Data: Depth: Records:	8 bit 4096 smpl 31

4 Our signal file containing all of 31 records has been loaded as Ch 4, in between Ch 1 and Ch 2.

👪 GageScope for Windows - [System1:Display1]	
	; , , , , , , , , , , , , , , , , , , ,	
	i 💤 🛱 🕇 🛛 bits 🝸 🐔 🖻 🔳	
Info View I I25 MS/s Name Value Ch 1 Ch 1 Ch 4 I of 31 Ch 2 I of I of I of I of <td< td=""><td>Timebase: 10us M.Pos: 50.0us</td><td></td></td<>	Timebase: 10us M.Pos: 50.0us	
CS2125 Trigger Depth Averaging Total 130944 Fine Units: Smpl Prefing 0 Auto 5.00 s Post Trig 4006 MulRec 31	General Settings Timebase Channel Name ▲ 10us/d ♀♀Ch1 ♀♀℃Ch2 ★ vpbd	Vert. Scale Vert.
🐙 System I		

Note

You can also save only the visible portion of the channel by checking the box at the bottom of the Save Dialog (just as you can with a non-Multiple Record acquisition).

Scope Mode

The automatic sample rate and input range selection feature allows GageScope[®] to be setup like a conventional digital oscilloscope. When the Scope Mode icon is pressed in or the Scope Mode check box in Preferences dialog box is checked, GageScope[®] is said to be in the **Scope Mode**. In Scope Mode, GageScope[®] automatically selects the signal input range in accordance with the selected vertical scale in Volts/division. The sample rate for the input signal is also automatically selected and is linked to GageScope's timebase in seconds/division.

How it works

Automatic Input Range selection

1 The figure below shows a 1 MHz sine wave being captured on Channel 1 of the CompuScope 8500 high speed A/D card.

🚰 GageScope (Professional edition) ver. 3.0	- [CS8500:YT1]	
Eile ⊻iew <u>C</u> apture <u>I</u> ools <u>W</u> indow <u>H</u> elp		×
🎯 🔛 🧉 🏨 ⇒ 🛃 🝩 🆐 🗶 [;	1;;;;) € € ≋ ∧ ≠	
률 🛺 रिंग के कि कि कि कि कि कि कि कि	┉ Ұ Ұ ⊨ ୫ 💽 🗹 🛙	
Analysis View II x 500 MS/s	ηηηη	ΛΛΛΛΛ
Ch 01		
Watch1 Create a new	M.Pos: 5.0us wanalysis channel	
CS8500 Trigger Depth	General Settings	CS Input Trace Drawing
Sample rate: 500 MS/s SuperRes Rot C58500 C61100	Channel Na	Coupling AC Range: ±200 mv Probe: x1 Dependent of MOhm Probe: x1 Coupling AC S0 Ohm Dependent of MOhm

2 The input signal amplitude is close to one volt. This signal has been clipped since the input voltage range setting is intentionally selected to be ± 200 mV. This is shown in the Channel Control setting for Channel 1 as follows:

CS Input	Trace Drawing			
	Coupling: AC			
Range: ±200	my V Fo Ohm 1			
Probe: Ut	SU Uhm			
In In				

3 The display setting for channel 1 is set to be one volt per division. This can be viewed by clicking the **Trace** tab for channel 1 in the channel control which is located in the bottom right of the GageScope[®] display. The **Trace** tab property page is shown as follows:

CS Input	Trace	Drawing	
-Vert. Scale-		div	Invert
Units	~	Ŧ	
∿ ∧∥ <mark>∧</mark>	<mark>,</mark> Ch 01		

Note that GageScope[®] is not operating in the Scope Mode as yet.

4 Click on the Automatic Sample Rate and Input Selection Rate Icon. You will notice that the Scope Mode appears on the display underneath the 500MS/s sample rate text. This implies that the input mode of CompuScope is now the Scope Mode. As a result the GageScope[®] display will automatically select the input range of the input signal according to the currently selected vertical display range (1V/div). You will see the changes in display as follows:

🔀 GageScope (Professional edition) ver. 3.0 🛛 -	🖻 GageScope (Professional edition) ver. 3.0 - [CS8500:YT1]					
Eile View Capture Lools Window Help		X				
Image: Second state Image: Second state	1;;; €.€. ≋∧.↗ □ {; {;} ≙. ≤					
Into View Name Value Score Mode Mode Ch 01 For Help, pres	Timebase: 1 us M Por 5 Ous					
CS8500 Trigger Depth	General Settings	CS Input Trace Drawing				
Sample rate: 500 MS/s P Superfice - Single Bbit - Single	Timebase Channel Na 1 us/d Chonnel Na	Couping AC DC DC DC DC Strain DC Probe: x1 Probe: x1 Probe: x1 Probe: x1				

Note that the input signal now no longer appears clipped. *The input voltage range is automatically adjusted to correspond to the currently selected vertical display range (1V/div)*, resulting in displaying the original 1 MHz sine wave.

5 As a result of the CompuScope 8500 being in the Scope Mode, the Range setting under CS Input tab in the Channel control has been changed from ±200mV to ±1V. Note that the Range text box is disabled so it appears dimmed out. This is done to ensure that the user is unable to change the range while the Scope Mode is active.

CS Inp	put	Trace	Drawing	
			Coupling:	AC
Range:	± 1 .	v 🔻		DC 50 Ohm
Probe:	x1	T D	ecimation	1 MOhm
	Г П <mark>4</mark>	- Ch 01		

The **Sample Rate** Option under **CS8500** tab in the System Control is also disabled. The CS8500 tab is located in the System Control area in the left bottom corner of the GageScope[®] display.

CS8500 Trigger Depth		
Sample rate: 500 MS/s 💌		
SuperRes Single		
Bbit 🗧		
💉 CS8500 💉 CG1100		

6 The Scope Mode can also be activated or deactivated by selecting Scope Mode in the **Preferences** dialog box.

Click Tools in the menu bar. The drop down menu appears:



7 Click **Preferences** to view the Preferences dialog box:

Preferences	X
Directories	
Load signals from: .\Signal Files	
Save signals to:	
Autosave configuration	S.asf
Miscellaneous Accept long file names Smart tabs Show tool tips Independent	t Trigger IV Scope mode
DM Buffer Max. Size, N	1B 16 🚍
Default Trace Alignment	Default action on stop acquisition:
O by Start 💿 by Trigger O Smart	Do not display Abort dialog Always wait C Always abort
MulRec Player speed	Slow
Associate GageScope files (*.	sig) to this application
	Cancel

The Check mark besides Scope Mode shows that the Scope Mode is currently active. When the Scope Mode is activated by clicking the Scope Mode Icon in the GageScope[®] toolbar, a check mark is simultaneously placed in front of the Scope Mode in the Preferences dialog box, signifying that the Scope Mode is active.

8 Deselect the Scope Mode by clicking inside the check box. The check mark disappears. Click **Apply**. You will see the following:

🖾 GageScope (Professional edition) ver. 3.0	- [CS8500:YT1] Google 🖃	×
Eile View Capture Tools Window Help	_ [8] >	×
🎦 🔛 🗁 🍓 ⇒ 🔁 🝩 🌤 🗡 📜	11; # QQ ≋ 🔨 🥏	
🖕 🏎 🕅 तेत तिल्ल 🖓 🛛 स्थ 🕨 🖄 🖬 स्थ	〃 糸 糸 ⇔ ≤	
Info View →IXIX Name Value Ch 01 Pe		
Ready	Timebase: 1 us M.Pos: 5.0us	
CS8500 Trigger Depth Sample rate: 500 MS/s Ciginal Concerning Single	General Settings Timebase Ua7d Channel Na Couping: AC Couping:	

Note that Scope Mode text is now taken off the display indicating that the Scope Mode is no longer active.

Also note that the **Range** setting is not reverted to the original value of ± 200 mV and the Sample Rate and Range text box controls have been enabled.

Automatic Sample Rate selection

1 A 1 MHz sine wave being captured on Channel 1 of the CompuScope 8500 high speed A/D card is shown below:

🚰 GageScope (Professional edition) ver. 3.0	- [C\$8500:YT1]	
Eile View Capture Iools Window Help		_ 8 ×
) × 🐳 🚭 💁 ⇐ 🚉 🕾 📓 📽 או 11 ੯ ଏ או 🙀 אן אן א	₩ \$ @ @ ≋ ^ / ₩ ₭ ₭ A 5 1 1 1 1	
Name Value 500 MS/		·
chor J ^e		<u>/</u>
		•
Watch1 For Help, p	ress F1	NUM
CS8500 Trigger Depth Sample rate 500 MS/s V SupeRes Biblit 2 CS8500 CS1100	General Settings Timebase Channel Na US/d CS Input Trace C Range: ±200 mv Probe: x1 mp Import Import	eupling: AC DC 50 Dhm edance: 1 MDhm

For the signal shown above, the post trigger depth is set to 4096 samples and the input range is ± 200 mV. The timebase setting is set to 1 us/d (microsecond per division).

2 Launch the **Scope Mode** by clicking on the Scope Mode Icon in the toolbar. You can also put a check mark in the Scope Mode check box in the Preferences dialog box as explained in the previous section. The text **Scope Mode** appears on the left side of the display, as shown below:

🚰 GageScope (Professional edition) ver. 3.0	- [CS8500:YT1]	
Eile ⊻iew <u>C</u> apture <u>I</u> ools <u>W</u> indow <u>H</u> elp		_ B ×
, איז	1;;;; €€ ≋ ∧ ≠ ∞ ₭₭₽ ≤	
Info View 32 X Name Value Scope Mode Ch01 2+	Timebase: 1 uz M.Poz. 5.0uz	
For Help, pro		NUM
CS8500 Trigger Depth Sample rate: 500 MS/6 × SuperRes Single Blue CS8500 CG1100	General Settings Timebase Usr/d Channel Na Rang Probe CS Cannel Na Cannel Na Comparison	Input Trace Coupling AC DC DC DC DC DC DC DC DC DC D

3 Change the timebase to 2 us/d by clicking once on the time base compression button, $\mathcal{N}\mathcal{N}$. The GageScope[®] display will appear as follows:

GageScope (Professional edition) ver. 3.0	- [CS8500:YT1] CCCC	_ 8 ×
Eile ⊻iew <u>C</u> apture <u>I</u> ools <u>W</u> indow <u>H</u> elp		_ 8 ×
🎯 🖬 🚑 禛 ⇒ 🛃 🚳 🌤 🛪! [;	1, ; ; , , , , , , , , , , , , , , , , ,	
🖕 🛺 Jat fixi 🎥 🛯 או די 🖄 דו דו ד	₩ 44 16 5 7 12 11 12	
Info View 250 MS/s Name Value Scope Mode		
Watch1 For Help, pr	Timebase: 2 us M.Pos: 10.0us	NUM
CS8500 Trigger Depth	General Settings CS Input Trace	
Sample rate: 250 MS/s V SuperRes: Single Bba -	Couping: AC Couping: AC Coupi	Jhm J Dhm

Note that the sample rate has changed to from 500 MS/s to 250 MS/s. GageScope[®] automatically adjusted the sample rate to account for this change in the timebase setting from 1 us/d to 2 us/d. The input range was also changed from ± 200 mV to ± 1 V.

⁴ Click on the **Scope Mode** Icon 1 to deactivate it. You can also check off the Scope

Mode setting in the **Preferences** dialog box as explained in the previous section. GageScope[®] will no longer be in the Scope Mode as shown below:



Decimation Mode

Decimation is a feature by virtue of which a user can view large amounts of data within GageScope. The user must first specify the amount of RAM needed for viewing desired amount of data. The amount of data needed per channel is specified in megabytes in the **Deep Memory (DM) Buffer** setting in the **Preferences** dialog box.

The size of the deep memory buffer is part of the actual physical RAM present in your system. The DM Buffer size must be between 8-64 megabytes. Care must be exercised in specifying a value for the DM buffer size.

The Decimation Mode is enabled when the size of acquisition per channel is more than 1/4th the size of the DM buffer size. Let us assume that you have allocated 8 MB for the Deep Memory buffer. In this case, the Decimation Mode will be automatically activated whenever you specify more than 2 MB of total acquisition length in GageScope. The total acquisition length is the sum of the pre and post trigger data size. The Decimation command button will then be enabled, signifying that the Decimation mode is currently active.

When working in Decimation mode, the user can select the starting sample and the number of samples to be downloaded from CompuScope acquisition memory. Only these data are then decimated and displayed.

Decimation functionality has also been incorporated in the Multiple Record mode. When working in Multiple Record mode, the user may now select the starting record and the number of records to be downloaded from CompuScope acquisition memory. Only these data are then decimated and displayed.

GageScope[®] uses skip samples, mean, and min max methods of decimating the data. The details of these methods and other decimation features are given in the following example:

How it Works

1 Open the **Preferences** dialog box by clicking on **Tools --> Preferences**. The Preferences dialog box will appear as follows:

Preferences
Directories
Load signals from: ASignal Files
Save signals to: \\Signal Files
Autosave configuration
Miscellaneous Image: Constraint of the second se
DM Buffer Max. Size, MB 16 👱
Default Trace Alignment Default action on stop acquisition:
by Start by Trigger Smart Do not display Abort dialog G Always wait Always abort
MulRec Player speed
Fast Slow
Associate GageScope files (".sig) to this application
Cancel

The Deep Memory Buffer size is set at 16 MB as shown in the DM text box. The maximum DM buffer size can be 64 MB.

Click Apply

2 Shown below is a 1 MHz sine wave captured by a CompuScope card and displayed as Channel 1.

GageScope (Professional edition)		Gage Iax
Eile ⊻iew ⊆apture Iools Window Help		X
]1;;;;] @. Q. ≋ ∧ 🥒	
률 🛺 fat fixi 🔐 🗰 🕨 🗩 🗊 199	₩ K K A S T 🖾 🛙	
Info View 500 MS/s		E
Name Value		£
	ΛΛΛΛΛΛΛΛΛ	
Ch 01		
		·····
	g.,	
Beady	/ Timebase: 2 us M Pos: 10 Ous	
Watch1 For Help, pr	ess F1	
CS8500 Trigger Depth	General Settings	CS Input Trace Drawing
Total: 1 G Smpl 💌 Fine	Timebase Channel Na	Coupling: AC
PreTrig 0 Auto 10.0 ms	2 us/d ⊠ A→ Ch 01	Range: 2200 mv - 50 0hm
PostTrig 1048576 MulRec		Probe: x1 Decimation 1 MOhm
CS8500 CG1100	CS8500:YT1 CG1100:YT1	

The acquisition post trigger depth is set at 1 Mega Samples (1 MS) as shown in the **Post Trig** text box in the System Control:

CS8500 Trigger Depth
Total: 1 G Smpl 💌 Fine
PreTrig 0 + Auto 10.0 ms
PostTrig 1048576 🐳 MulRec
💉 CS8500 💉 CG1100

Note the total memory available for signal acquisition is 1 Giga Samples (1 G Smpl) as shown in the **Total** text box.

3 Let us now have a look at the Channel 1 property page, which is located in the right bottom corner of GageScope[®] screen:

CS Input	Trace Drawing
Range: 👥	Coupling: AC DC Imv - 50.0hm
Probe: x1	Decimation 1 MOhm
<u>~</u> , All <u>~</u>	- Ch 01

Observe that the Decimation command button is shown disabled implying that the Decimation mode is not currently invoked.

For the settings we have chosen for this acquisition, the criterion for the Decimation mode to be invoked is as follows:

GageScope[®] will decimate the input data whenever the acquisition length per channel (pre and post trigger) exceeds 4 MB.

Note that the 4 MB is one quarter of the DM Max. Buffer Size of 16 MB. The Decimation Mode is enabled whenever the size of acquisition per channel is more than $1/4^{\text{th}}$ the size of the DM buffer size. Since the acquisition depth is currently set to 1 MB for Channel 1, the decimation Mode is not invoked.

4 Change the total acquisition depth for Channel 1 to 8 MB. As soon as you change the total signal acquisition depth and click anywhere within the display, GageScope[®] will start decimating the input data and display it on Channel 1 as follows:

Note that the data on channel 1 is now being decimated. By default, a user gets to view the best representation of the input data.

One of the three methods is employed for decimating the input data: Skip Sample, Mean, or Min Max. A method of your choice can be selected from within the **Decimation** dialog box. The decimation dialog box opens up whenever the Decimation command button is clicked. Make sure that the Decimation button is enabled before you click on it.

There are several other useful features available within the decimation dialog box. A detailed descriptions of these features and their use is given as follows:

5 Click on the **CS Input** tab of Channel 1 control. The property page appears as follows:

CS Input	Trace Drawing
	Coupling: AC
Range: +200	
- 12200	
Probe: x1	Decimation 1 M0hm
<u>~</u> , All <u>~</u>	- Ch 01

Note that the Decimation command button is shown enabled.

6 Click on **Decimation** button. The **Decimation** dialog box opens as shown below:

Decimation			X
Source: Ch 1	of CS8500		
<u>S</u> tart:	0 •	0	8388592
Size:	8388606 •	16	8388608
Start <u>R</u> ecord:	1	1	1
Re <u>c</u> ords:	1	1	1
Faster	524297	2	524297
Factor:	J24207 •	-	324207
<u>Т</u> уре:	Skip Samples 💌	Min	Мах
	ОК	Cancel	

7 The **Decimation** dialog box options are as follows:

Source	Shows the channel number being decimated and the name of the CompuScope card. It can also be the name of the file, if the signal is loaded from a file.
Start	The starting sample of the data to be displayed. Note that the current range of data values spans from the Minimum Sample value of zero to the Maximum Sample value of 8388592. These are the values in the corresponding row as shown in the Min and Max columns on the right side of the text box.
	Min is the minimum number that a user can select for the corresponding feature. For example the Minimum Factor a user can select is 2 as shown in the Decimation dialog box.
	Max is the maximum number that a user can select for the corresponding feature. For the current setup, 524287 is the Maximum Factor a user can select.
	The user can select any number from within this range. Since the maximum size of the signal to be displayed in the Decimation Mode is 16, the Maximum Start Sample Number (Max.) is set to be signal acquisition depth minus 16.
Size	The total number of samples to be displayed.
	The number in the size text box refers to the total length of the signal to be displayed.
	Note that no less than 16 samples can be displayed on the decimated channel. The maximum number is the acquisition depth per channel specified in the Pre and Post Trig text boxes in the System Control. In our case the total acquisition depth is 8 MB, which turns out to be 8388608 as shown in the corresponding column.

Start Record	The number of the starting record to be displayed in a Multiple Record acquisition. Presently, there is only one single record being captured. When the Multiple Record Mode is invoked, you will see the Min and Max numbers in the corresponding columns.
Records	The total number of records to be displayed in the Multiple Record Mode.
	The Maximum number of records equals the total CompuScope memory available for acquisition divided by the acquisition depth per channel.
	The minimum number of records to be displayed is obviously one.
Factor	This is the Compression Ratio. Compression ratio can be chosen from the available range of minimum and Maximum values.
	Decimation is a process of compressing the data so that it can be displayed in GageScope.
	Note that the best compression ratio corresponds to maximum number in the corresponding row in Max column. In the present example, you can see that the factor is chosen to be the Max by default.
	The minimum compression ratio will display the maximum number of samples. This will give the best possible representation of the entire acquisition.
	The best compression ratio is the one that retains key features of the signal to be displayed. This number is left to the user's discretion.

TypeThere are three types of decimation methods available:Skip Samples: Skips samples automatically according
to the Factor (Compression ratio)Mean: Takes the mean value of a group of samples.
The size of this group is governed by the number
entered as the Factor.

Min Max: Depending on the **Factor**, takes the Minimum and Maximum values of a group of samples. These values are then displayed in a vetical line connecting the minimum value to the maximum value.

8 Getting back to our example, click **OK** in the Decimation dialog box. You will get back to the signal being acquired and decimated:

According to the current Decimation settings, the Skip Sample method is used to decimate the input data shown in the figure above.

9 There are two other methods of decimating the data: MinMax and Mean.

The MinMax Method

In MinMax method, as the first step, the entire acquisition is divided into groups of samples. Each group contains fixed number of samples. The number of groups and the size of a single group depend on the number entered in the **Factor** text box in the Decimation dialog box. User has no direct control in specifying the number of samples to be grouped.

Next, the minimum and the maximum value from each group is extracted and saved. Fro each group, a vertical line is then displayed. The two end points correspond to the minimum and maximum value of the selected group. There will be as many vertical lines as the number of groups.

10 In order to use the **MinMax** method of decimating the data, click on the decimation button in the channel control. The decimation dialog box appears. Click on the Type drop down menu button. The **Type** menu will appear:

Decimation 🔀			
Source: Ch 1	of CS8500		
<u>S</u> tart:	0	0	8388592
Size:	8388606 •	16	8388608
Start <u>R</u> ecord:	1	1	1
Re <u>c</u> ords:	1 .	1	1
	F 2 4207		534307
<u>F</u> actor:	524287	2	524287
<u>T</u> ype:	Skip Samples 💌	Min	Max
	Mean Min/Max Skip Samples	Cancel	

11 Click **MinMax** from the list. MinMax shows up in the Type text box:

🚟 GageScope (Professional editio	in)				_8×
Eile View Capture Lools Wind	low <u>H</u> elp				_ @ ×
≝∎ ⊴ ⋭⇒⊵⊃	ii> x! [; †; ;	Q Q ₿	š Λ 🖉 👘		
for the fat fixe 🏤 🔤 🗈	SIIN M M	6 6 3	8 bits 🔻 🖆	1 TE	
Info View Info	500 MS/s			· · · · · · · · · · · · · · · · · · ·	<u> </u>
Name Value					
	Decimation			×	
	Source: Ch 1 of CS85	00			
	Start: 0	<u> </u>	0	8388592	
	Size: 83886	02	16	8388608	
	Start <u>R</u> ecord: 1	*	1	1	
	Records: 1		1	1	
	Eactor: 52428	7 🗄	4	524287	
	Lype: Min/N	lax 🔽	Min	Max	
March1		OK	Cancel		
CS95001 Trigger Depth]	Gener	al] Settings	1	CS longt	
	- Timeb			- 1	Counting AC 1
Total: 1 G Smpl ▼ Fine Channel Na Couping: AL					
Preing 0 → Auto 100 ms 50 0 hm					
💉 CS8500 💉 CG1100		8500:YT1 📐	G1100:YT1		Ch 01
🏽 🕅 🏹 🏈 🗊 🖾 🛱 🕅 Gag	eScope (Professi	💐 Paint Shop P	ro-Decim_M		11:54 AM

12 Click OK. You will see channel 1 decimated input data as follows:

🖼 GageScope (Professional edition)		GaGe BB×
Elle ⊻iew Capture Iools Window Help		_ @ ×
	# 1# # Q Q 窓へタ ッ Қ Қ 烏 8 bits マ 箇 田 国	
<u>Name</u> Value Ch 01 ✔	╸ ┍╴╴╄╍╶┠╍╌┠╺╍╎╴╺┥╴╸┥╸╸┥╸╴┠╸╶┠╸╴┼╸	
Uecima Watch1 For Help. p	T ting Timebase: 2 ms M.Pos: 10.0ms ress F1	
CS8500 Trigger Depth Totat 1 G Smpl * Fine Piet Ing 0 ±± Auto 10.0 ms Postfrig 8398008 ±* MulRec MulRec CS8500 CG1100 CG1100 CG1100	General Setting: Timebase Channel Na. Channel Na. Cha	S Input Trace Drawing Couping AC DC S0 Drm status of the status of

Observe that the data is displayed as vertical lines. The number of lines represent the size of the decimated data to be displayed. Divide the **Size** of the data to be displayed by the **Factor** to get the size of the decimated data.

In the current example, we have

Size (data to be displayed) = 8388606Factor = 524287Decimated DataSize = Size/Factor = 8388606/524287= 16

Now count the number of vertical lines. You will notice that there are 16 shown in the display above.

13 The Mean Method

In Mean method, same as in the MinMax method, the entire acquisition is divided in groups of fixed length. The mean value for the samples in each group is computed. These mean values for the entire acquisition are then displayed as the decimated data.

14 In order to use the **Mean** method of decimating the data, click on the decimation button in the channel control. The decimation dialog box appears. Click on the Type drop down menu button. The **Type** menu will appear:

Decimation			×
Source: Ch 1	of CS8500		
<u>S</u> tart:	0 *	0	8388592
Size:	8388606 -	16	8388608
Start <u>R</u> ecord:	1	1	1
Re <u>c</u> ords:	1	1	1
Eactor:	524287	2	524287
<u>T</u> ype:	Skip Samples 💌	Min	Max
	Mean Min/Max Skip Samples	Cancel	

15 Click **Mean** from the list. Mean shows up in the Type text box. Click OK. You will the decimated signals as follows:

🖼 GageScope (Professional edition)		GaGe - B×	
Eile ⊻iew Capture Iools Window Help		_ @ ×	
ଅଅଜା⇒ଢିତ୍ର×ା	11; ; €. €. ⊗ ∧ 🥒		
률 du fat fix 🔐 🕅 🕨 🖄 🛛 HAI	₩ 14 14 15 8 bits 💌 🕮 🛄 🕻		
Info View INfo Store Store Name Value			
Ch 01 -		<u>ar ann an ann an an an an an an an an an a</u>	
	T		
Watch1 For Help, pr	Timebase: 2 ms M.Pos: 10.0ms ess F1		
CS8500 Trigger Depth	General Settings	CS Input Trace Drawing	
Total 1 G Smpl Fine PreTrig 0 = Auto 10.0 ms PostTrig 8388608 = MulRec	Timebase Channel Na 2 ms/d ♀ Ch 01	Coupling: AC nge: ±200 mv DC 50 0hm 50 0hm sbe: x1 Decimation	
💉 CS8500 💉 CG1100	CS8500:YT1 CG1100:YT1	→ All	

Observe that the decimated data according to the Mean method indicates that there is a small neative bias in the signal. Thus the decimated data canbe used to observe and even measure trends in the acquired signals.

16 In order to further elaborate the Mean method of decimation, shown below is a sine wave with a positive DC offset added to it:

🖬 GageScope (Professional edition)		GaGe -BX
Eile View Capture Lools Window Help		_ 8 ×
	. "t; ; Q Q ≋ ∧ <i>⊅</i>	
🏚 Au Jat fixi 🔐 🕅 🕨 🗂 II HH	>>> K K 🏠 S 8 bits 🔽 🎦 🗉 🗉	
Info View 1x Name Value Ch 01 F		
Watch1 For Help, pi	y Timebase: 1 us M.Pos: 5.0us	
CS8500 Trigger Depth Totat 16 Smpl = Fine Protrag 0-3 Auto 10.0 ms PostTrig 1048576-3 MuRec MuRec CS8500 CC1100 CC100 CC100	General Settings Imebase Channel Na Imebase Probe: 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Drawing Coupling: AC DC DC ST OPm 1 MDhm
🎢 Start 🛛 🖉 🍘 🖏 🛛 🆓 Paint Shop Pro	GageScope (Professi 🔤 Calculator	💾 🚈 1:41 PM

17 Follow the steps in the previous sections to obtain the decimated data emplying the Mean method. The decimated data is shown as follows:

You can see that the positive DC offset now appears as the decimated data.